


S/M No.: FT32600001

Service Manual


Refrigerator

RF-T405N../RN-T405N..




RFT-326..

RF-T425N../RN-T425N..



RFT-346..

RF-T455N../RN-T455N..



RFT-356..

✓ Caution

In this manual, some parts can be changed for improving their performance without notice. So, If you need the latest parts information, please visit and refer to PPL (Parts Price List) in Service Information Center. (<http://svc.dwe.co.kr>)


1. Model Information

** is option code*

Refrigerant Type		R-134a			R-600a		
Model No.		RF-T405N**	RF-T425N**	RF-T455N**	RN-T405N**	RN-T425N**	RN-T455N**
Control Type		FCP Touch control					
Gross Vol. (ISO 15502)	Total	365	375	404	365	375	404
	Freezer	120	120	120	120	120	120
	Refrigerator	245	255	284	245	255	284
Storage Vol. (ISO 15502)	Total	315	332	358	315	332	358
	Freezer	90	90	90	90	90	90
	Refrigerator	225	242	268	225	242	268
Diemension	Width	595	595	595	595	595	595
	Depth	651	651	651	651	651	651
	Height	1857	1897	2000	1857	1897	2000
Cooling Cycle	Refrigerant Charge	0.095kg			0.040kg		
	Evaporator Type	Fin Type					
	Condenser Type	Fan Cooling System					
	Dryer	Molecular Sieve xH-9					
	Capillary Tube	ID0.7 x T0.55 x L2320					
	Defrost Type	Automatic Start & Stop					
Heater	Defrost Heater	AC230V, 180W			AC230V, 160W		
	Defrost Shape	Glass Type			Sheath Type		
Electric Part	Freezer Fan Motor	AC 230V/50Hz or DC 12V					
	Condenser Fan Motor	AC 230V/50Hz or DC 10V					
	Refrigerator Lamp	LED					
Weight		67	69	73	70	72	76
Blowing Agent		C-Pentane					


2. Interior Parts

※ The real features are model dependent



- | | |
|----------------------------------|----------------------------------|
| 1. Freshfood compartment LED | 7. Temperature control Knob |
| 2. Multi-Duct | 8. Freezer Case (3EA) |
| 3. Freshfood compartment Shelves | 9. Adjustable Foot |
| 4. Fresh Care Crisper (option) | 10. Dairy Pocket |
| 5. Wine Keeper (option) | 11. Freshfood compartment Pocket |
| 6. Vegetable Case | |

3. Refrigerant Cycle




- Welding Point


●	Copper Welding (Ag 5%)	6 Point
■	Silver Welding (Ag 30%)	3 Point

4. Wiring Diagram

- For AC Motor




- For DC Motor (Europe)



1. DISPLAY			
INPUT		CONTROL OBJECT	
PCB Control Panel Buttons		PCB Control Panel LED	
No	LED DISPLAY	FUNCTION	OPERATION
1	3rd LED	TEMP STEP "NOR"	Initially position
	4th LED	TEMP STEP "MAX-NOR"	Push "TEMP" button 1 times.
	5th LED	TEMP STEP "MAX"	Push "TEMP" button 2 times.
	1st LED	TEMP STEP "MIN"	Push "TEMP" button 3 times.
	2nd LED	TEMP STEP "MIN-NOR"	Push "TEMP" button 4 times.
	LED "S-COOL" on	TEMP S-COOL	Push "S-COOL" button 1 time.
2	3rd LED is on/off	ERROR R SENSOR.	[Error display] Push "TEMP" button 5 times while opening Refrigerator door . The Priorities of Error : R SENSOR> RT SENSOR> DR S/W> CYCLE> DEFROST
	2nd LED is on/off	ERROR RT SENSOR	
	1st LED is on/off	ERROR D SENSOR	
	2nd & 3rd is on/off	ERROR DOOR S/W	
	1st & 3rd is on/off	ERROR "CYCLE"	
	1st & 2nd is on/off	ERROR "DEFROST"	
3	3rd LED and "S-COOL" LED is on.	Forced (Quick) Defrost Test	Push "S-COOL" button 5 times while opening the refrigerator door. (not Error)
4	1st LED and "S-COOL" LED is on	Pull Down Test	Push "TEMP" button 30 times. (not Error)

2. Temperature Control of Refrigerator Compartment																	
INPUT			CONTROL OBJECT														
PCB Control Panel "TEMP" Buttons R-sensor			PCB Control Panel LED COMPRESSOR, FAN														
<p>A. "TEMP" Button</p> <ol style="list-style-type: none"> 1. Temperature control of Refrigerator compartment 2. 5 step mode of successive temperature mode 3. Initial mode by power input: step "NOR" 4. Temperature will be set if the button doesn't get pressed again within 5 sec. <ul style="list-style-type: none"> - Whenever pressing "TEMP" button, setting is repeated in the order of "NOR" → "MAX-NOR" → "MAX" → "MIN" → "MIN-NOR" (LED LAMP ON) <p>B. Temperature of Refrigerator Control</p> <ol style="list-style-type: none"> 1. COMP and FAN will be controlled by the on/off condition of each mode.1 2. Temperature Difference of Refrigerator each step : <table border="1" style="width: 100%; text-align: center;"> <thead> <tr> <th>Temperature Step</th> <th>"MIN"</th> <th>"MIN-NOR"</th> <th>"NOR"</th> <th>"MAX-NOR"</th> <th>"MAX"</th> </tr> </thead> <tbody> <tr> <td>Temp. Diff. of Each Step</td> <td>1.3C</td> <td>1.5C</td> <td>2.3C</td> <td>2.2C</td> <td></td> </tr> </tbody> </table> <p>3. Temperature of Refrigerator at step "NOR" OFF point: is -1.2C</p> <p>4. Refrigerator ON/OFF Temp. Difference: 3.4C</p> <p>C. "S-COOL" MODE</p> <ol style="list-style-type: none"> 1. Press S-COOL SWITCH and make S-COOL led lamp on. 2. COMP & FAN are on until R-sensor reaches to "Over Refrigeration OFF Point", -7C 3. After the reach of -7°C , STEP "MAX" mode continues. 4. When "S-COOL" MODE (Quick Refrigeration Mode) lasts for about 40 minutes, it returns to general operation mode. <p>D. Temperature of Freezer Control</p> <p>-It will be only controlled by using "KNOB F LOUVER" in Freezer.</p>						Temperature Step	"MIN"	"MIN-NOR"	"NOR"	"MAX-NOR"	"MAX"	Temp. Diff. of Each Step	1.3C	1.5C	2.3C	2.2C	
Temperature Step	"MIN"	"MIN-NOR"	"NOR"	"MAX-NOR"	"MAX"												
Temp. Diff. of Each Step	1.3C	1.5C	2.3C	2.2C													

3. Defrost Mode																	
INPUT	CONTROL OBJECT																
Total COMP Work Time / COMP Working Rate Total Door Open Time / RT	Defrost Mode																
<p>Conditions of Defrost Mode</p> <p>A. When total operation time of compressor becomes: 6, 8, 10, 12 hours. - any error mode-R1, D1, F3, C1, RT/S, Door SW error- happens. - or, running rate of COMP (per 2hrs of total operation time) is more than 80%. - or, total door open time is over 3 minutes. - or, ambient temperature (RT) is more than 40C.</p> <p>B. Even if the above condition "A" is not satisfied, - Defrost mode starts immediately when total operation time of COMP is 14hrs. - or, defrost mode starts immediately as long as total time (COMP on time + COMP off time) is 60 hrs.</p> <p>Defrost Mode</p> <p>A. General Defrost Mode - How to start: By conditions of defrost - Process : General operation- "PRE-COOL" - Defrost Heater on- Pause(10 min)-General operation ; PRE-COOL: When the defrost heater works, the temp. of freezer increases. So the COMP works for 25 min before defrost mode. - Limited Time of Defrost Heater ; 40 minutes: Heater turns off when "D SENSOR" is OPEN or SHORT. ; 60 minutes: Heater turns off after maximum 60 minutes. - Heater Off: When the temperature at "D SENSOR" is over 10C</p> <table border="1"> <thead> <tr> <th></th> <th>PRE-COOL</th> <th>Defrost</th> <th>Pause</th> </tr> </thead> <tbody> <tr> <td>Compressor</td> <td>ON</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>Fan</td> <td>ON</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>Defrost</td> <td>OFF</td> <td>ON</td> <td>OFF</td> </tr> </tbody> </table> <p>B. Forced(Quick) Defrost Mode - How to start: push the "S-COOL" button 5 times while opening the refrigerator door. - Process: same as General Defrost Mode except "PRE-COOL" ; Heater is supposed to be on Initial 30 seconds even though the temp. at "D SENSOR" is over 10C. (for TEST) - How to confirm: Push "TEMP" button 5 times while opening the refrigerator door.. And then, the mode displays. - Display : 3rd & "S-COOL" LED is on/off continually</p>			PRE-COOL	Defrost	Pause	Compressor	ON	OFF	OFF	Fan	ON	OFF	OFF	Defrost	OFF	ON	OFF
	PRE-COOL	Defrost	Pause														
Compressor	ON	OFF	OFF														
Fan	ON	OFF	OFF														
Defrost	OFF	ON	OFF														



4. Prevention of Compressor Restart	
INPUT	CONTROL OBJECT
	COMP
<p>COMP. doesn't work after COMP turns off even though R-sensor is on condition. (This is to protect comp.)</p> <p>A. General operation (Temp. at the RT sensor is over 20C): The COMP can't be on within 6 min.</p> <p>B. Operation of LOW RT (Temp. at the RT sensor is below 19C): The COMP can't be on within 30 min. (But the COMP can be on after 6min when the doors open more than 20 seconds.)</p>	


5. Buzzer Sound	
INPUT	CONTROL OBJECT
Control Buttons / Door Switch Initial Power Input	Buzzer
<p>A. Whenever "PCB Control Panel" button's pushed, the buzzer rings.</p> <p>B. After 2 minutes power's on, the buzzer rings 3 times.</p> <p>C. Time of Buzzer: Forced Defrost Mode (3 times), Short Circuit Test (1 time)</p> <p>D. When door opens, the buzzer rings every 1 minute for 5 minutes.</p>	

6. Control of R-sensor OFF Point

INPUT	CONTROL OBJECT
"J1", "J2" On Main PCB	Control Resistance of R sensor OFF Point

A. LOW COOLING OPTION (Weak Cooling)

- When the refrigeration of refrigerator is poor or weak though Fan and COMP are working continuously, the following actions are recommended for service.
 - Resistance (R47) : Default resistance (31.4Kohms)
 - Resistance (R45) : Cut the "J1" off to reduce basic resistance by 1.5°C. (2Kohms up)
 - Resistance (R42) : Cut the "J2" off additionally to reduce basic resistance by 1.5°C. (total 4Kohms up)
- R47 = R-SENSOR OFF point
R47 + R45 = R-SENSOR OFF point - 1.5C
R47 + R45 + R42 = R-SENSOR OFF point - 3C



7. Error Display											
INPUT	CONTROL OBJECT										
PCB Control Panel Buttons / Door	LED Lamp										
<p>- ERROR DISPLAY</p> <ul style="list-style-type: none"> - To check the appliance has error or not, push TEMP button 5 times while opening the refrigerator. door. - To stop the Error Display Set, push "TEMP" button 1 times, or wait 4 minutes. <p>A. R1 ERROR (It happens when R-Sensor is OPEN or SHORT)</p> <ul style="list-style-type: none"> - DISPLAY : 3rd LED is on & off continually. - CONTROL : <ul style="list-style-type: none"> ; Controlled by the following condition of RT ; When "RT ERROR" happens at the same time, "COMP. ON/OFF Operating Time" is 16min/24min. (Unit : min) <table border="1"> <thead> <tr> <th>RT sensor TEMP</th> <th>~13C</th> <th>~19C</th> <th>~29C</th> <th>29C ~</th> </tr> </thead> <tbody> <tr> <td>COMP. Operating TIME (ON/OFF)</td> <td>6/34</td> <td>10/30</td> <td>16/24</td> <td>20/20</td> </tr> </tbody> </table> <ul style="list-style-type: none"> - Termination : when R-Sensor is normal. <p>B. RT ERROR (It happens when RT-Sensor is OPEN or SHORT)</p> <ul style="list-style-type: none"> - DISPLAY : 2nd LED is on & off continually. - CONTROL : Delete the conditions of "RT-sensor Control" and operate normally. - Termination : when R-Sensor is normal. <p>C. D1 ERROR (It happens when D-Sensor is OPEN or SHORT)</p> <ul style="list-style-type: none"> - DISPLAY : 1st LED is on & off continually. - CONTROL : Defrosting is active maximum time (40 min) - Termination: when D-Sensor is normal. <p>D. DR ERROR (It happens when the system senses door opens more than 1 hour.)</p> <ul style="list-style-type: none"> - DISPLAY : 2nd & 3rd LED are on & off continually. - CONTROL : Deletion of function related door switch sensing - If door switch (open & close) is sensed, the error is terminated automatically. <p>E. C1 ERROR (When D-Sensor is more than -5C, Comp operates continuously over 3 hrs)</p> <ul style="list-style-type: none"> - DISPLAY : 1st & 3rd LED are on & off continually. - CONTROL : Normal operation. - Termination : When Comp is off, D-Sensor is less than -5C. <p>F. F3 ERROR (When defrosting is active for 60 minutes.)</p> <ul style="list-style-type: none"> 6.1- DISPLAY : 1st & 2nd LED are on/off continually. 6.2- CONTROL : Skip the Pre-cool process. 6.3- Termination: When defrosting ends by the defrost sensor. <p>- If the appliance is normal (no error), just 4th and 5th LED is on/off in Error Mode.</p>		RT sensor TEMP	~13C	~19C	~29C	29C ~	COMP. Operating TIME (ON/OFF)	6/34	10/30	16/24	20/20
RT sensor TEMP	~13C	~19C	~29C	29C ~							
COMP. Operating TIME (ON/OFF)	6/34	10/30	16/24	20/20							


8. Function Key Summary Table

MODE	Action	Button / Remark
Forced(Quick) Defrost Mode	How to enter the Mode	S-COOL 5 times + Refrigerator door open
	How to terminate	After mode end or unplug.
	Display	3rd and S-COOL LED is on.
Pull Down Mode	How to enter the Mode	TEMP button 30 times
	How to terminate	After mode end or unplug.
	Display	1st and S-COOL LED is on.
Error Display	How to enter the Mode	TEMP 5 times + Refrigerator door open
	How to terminate	After 4 minutes or unplug.
	Display	4th and 5th LED is ON/Off (When no error)




In Error Mode, you can find the current mode (What mode is operating) and what kinds of Error happen.

1. Front PCB (some parts can vary from the actual appearance.)

No	Procedure	No	Procedure
1	 <p>Remove cap cover.</p>	3	 <p>Pull the FCP FIXTURE UP by using (-)driver.</p>
2	 <p>Separate the F-PCB housing from refrigerator. Be careful not to scratch the cabinet surface.</p>	4	 <p>After separating F-PCB from fixture , change the FCP to new ones</p>


2. Door Switch

No	Procedure	No	Procedure
1	 <p>Remove top cover hinge screw with (+) driver.</p>	3	 <p>Remove the Door Switch from the cover hinge.</p>
2	 <p>Separate the Cover hinge by using driver. Be careful not to scratch the cabinet surface.</p>	4	 <p>Disconnect door switch connector.</p>


3. Multi-Duct As (In Freshfood Compartment)

No	Procedure	No	Procedure
1	 <p>Remove screw cap with (-) driver(2 points)</p>	3	 <p>Disconnect the Sensor wire housing.</p>
2	 <p>Unscrew 2 points with (+)driver</p>		



4. Freezer Louver As

No	Procedure	No	Procedure
1	 <p data-bbox="193 748 756 777">Unscrew the fixing screw to remove the Louver F As</p>	4	 <p data-bbox="863 748 1461 777">Remove 3 screws in order to disassemble Louver F As.</p>
2	 <p data-bbox="193 1178 676 1207">Remove the Louver F As pulling the top side.</p>	5	 <p data-bbox="863 1178 1362 1207">When disassembling check the Knob position.</p>
3	 <p data-bbox="193 1610 580 1639">Disconnect Fan motor wire housing.</p>	6	 <p data-bbox="863 1610 1094 1639">Default position is 'M'</p>



5. LED Lamp (In Freshfood Compartment)

No	Procedure
1	 <p data-bbox="193 701 619 779"><i>Using a thin driver, Pull both locker and Separate a Window LED from Liner.</i></p>
2	 <p data-bbox="193 1178 536 1211"><i>Unscrew 2 points with (+) driver</i></p>
3	 <p data-bbox="193 1608 584 1641"><i>Disconnect LED PCB form housing.</i></p>


How to change Door opening Dirction (Reversible)

No	Procedure	No	Procedure
1	 <p>Remove top cover hinge screw with (+) driver.</p>	6	 <p>Button Hidden Wire Cover Bushing</p> <p>After hiding door wire harness, remove the button Door Switch and Cover Bushing.</p>
2	 <p>Separate the Cover hinge by using driver.</p>	7	 <p>After unscrewing the Cover Hinge Harness *T *L, disclose the door wire harness.</p>
3	 <p>Remove the Door Switch from the cover hinge.</p>	8	 <p>Stopper</p> <p>Reassemble the cover and button door switch. And also assemble the door stopper to opposite side. (Which is located the Door under Cap.)</p>
4	 <p>Disconnect all wire connector and hinge.</p>	9	 <p>Freezer Door</p> <p>Remove the Middle Hinge. Assemble Cover Bushing & Stopper to the opposite.</p>
5	 <p>Refrigerator Door Cap</p> <p>Unscrew the Cover Hinge Harness *T *R and hide the door wire harness.</p>	10	 <p>a. Change the location (screw & division hinge cap)</p> <p>b. Change the unnder hinge location to the opposite.</p>

How to change Door opening Direction (Reversible)

No	Procedure	No	Procedure
11	 <p>Screw the middle hinge to fix the Freezer Door. (Washer should be up.)</p>	14	 <p>Connect the wire harness to door switch. (Be careful the dircetion.)</p>
12	 <p>Also assemble wire cover on the top plate. (On the right)</p>	15	 <p>Assemble Door and hing cover.</p>
13	 <p>Change the plate position and separate door switch.</p>		

1-1. Remove the Door As



a. Remove 'Top Cover Hinge' and 'Top Hinge'

b. Separate 'Refrigerator Door'.

c. Remove 'Middle Hinge'

d. Separate 'Freezer Door'.

e. Remove 'Cover Bracket'.

f. Remove 'Under Hinge'.


1-2. Reverse the Door Accessories

g. Reverse the position of 'Cover Bushing Refrigerator Door'
 - Unscrew and remove 'Harness Cover'.
 - Take out 'Left Door Harness' and assemble 'Harness Cover' on 'Right Door Harness'.


h. Reverse the position of 'Cover Bushing Freezer Door'.

i. Reverse the position of 'Door Stoppers'.

J. Reverse the position of 'Button Switch'.
 - Unscrew 'Button Switch'



1-3. Reassemble the Freezer and Refrigerator Door



j. Assemble the 'Under Hinge' on the left.

k. Attach the 'Freezer Door' to Cabinet.

l. Assemble the 'Middle Hinge' on the left.

m. Attach the 'Refrigerator Door' to Cabinet.
(Be careful not to fall down)

n. Assemble 'Top' hinge and connect the FCP wire.

o. Connect the 'Door Switch' wire housing.
Assemble the 'Door Switch' on the other side.

p. Assemble the 'Cover Bracket'.

1. Safety Warning (R-600a Refrigerant Models)



This appliance contains a certain amount of isobutane refrigerant (R600a) a natural gas with high environmental compatibility that is, however, also combustible.

When transporting and installing the appliance, care should be taken to ensure that no parts of the refrigerating circuit are damaged.

Refrigerant squirting out of the pipes could ignite or cause an eye injury. If a leak is detected, avoid any naked flames or potential sources of ignition and air the room in which appliance is standing for several minutes.

- In order to avoid the creation of a flammable gas-air mixture if a leak in the refrigerating circuit occurs, the size of the room in which the appliance may be sited depends on the amount of refrigerant used. The room must be 1m³ in size for every 8g of R600a refrigerant inside the appliance. The amount of refrigerant is shown on the identification plate inside the appliance.
- Never start up an appliance showing any signs of damage. If in doubt, consult your dealer.

2. Tools

<p>1. R-600a ref. Can</p> 	<p>2. Can adapter</p> 	<p>3. Pinch Plier</p> 
<p>4. Ref. discharging hose</p> 	<p>5. Vacuum pump</p> 	<p>6. Welder</p> 
<p>7. Coupling Pipe</p> 	<p>8. Leakage Tester</p> 	<p>9. Electronic-scale</p> 

3. Process Summary

1st Step.
R-600a ref. discharging

- Connect the discharging hose to the outdoors.
- Time : 7 min.

2nd Step.
Removing the remaning refrigerant

- For removing of remaning refrigerant., connect the discharging hose to the vacuum pump
- Time : 10min

3th Step.
Exchanging comp. & dryer / pipe welding

- Exchange Comp. and Dryer
- Welding the Pipe
- Copper-Copper : 5% rod
- Copper-Steel : 30% rod

4th Step.
Welding coupling pipe

Coupling cap and gas charging cap should be seperated before welding.


5th Step.
Vacuum

- Check the vacuum with (mani-polder) gauge
- Time : 60~80min


6th Step.
Charge R-600a

- Charging the ref. on POWER ON
- Time : 10min

4. In Detail Precess


NO.	SVC process	Image	Details
1	Connecting the pinch-plier & discharging hose		<ol style="list-style-type: none"> 1. Connect the discharging hose to the pinch-plier 2. The outlet of discharging hose should be placed to the outdoor(window)
2	Fixing the pinch-plier & charging pipe		<ol style="list-style-type: none"> 1. Fix the pinch-plier to the compressor charging pipe. 2. Pinch-plier should not be moving freely. <p>※ If that is moving freely, it would cause fire/explosion as leakage gas in the room.</p>
3	Discharging the R-600a ref.		<ol style="list-style-type: none"> 1. Discharge the R-600a ref. to outdoor. [Befor connecting the vacuum pump] <p>※ It should have enough time more than 7 minutes to discharge.</p>

NO.	SVC process	Image	Details
4	Removing the remaining ref.		<p>1. And then, connect the vacuum pump to the outlet of discharging hose</p> <p>※ Vacuum pump should be placed at the outdoor where is able to clear air easily.</p> <p>※ It should have enough time more than 10 minutes to discharge.</p>
5	Removing the pinch-plier & pipe		<p>1. Disassemble the each pipe (Del-pipe, Suc-pipe, Capi-pipe, Dryer & Hot-pipe)</p> <p>※ Caution ; A part is easily damaged by flame so that disassembly should be done carefully.</p>
6	Exchanging comp & dryer		<p>1. Change the comp. & dryer.</p> <p>※ You should check the comp. spec. and assemble correctly.</p>
7	Welding		<p>1. Weld the each pipe.</p> <p>※ ○ Copper-Copper welding - 5% rod △ Copper-Steel welding · 30% rod</p>
8	Disassembly of charging valve (Coupling pipe)		<p>1. Decap the couplig pipe cap and disassemble the vlave ass'y.</p> <p>※ If you don't disassemble, the coupling rubber would be melted.</p>


NO.	SVC process	Image	Details
9	Coupling pipe welding		<p>1. Weld after inserting the coupling pipe to the compressor.</p> <p>※ Use the wet cloth for preventing the other part of machinery-room from damage.</p>
10	Valve reas's'y & guage connecting		<p>1. Reassemble the valve ass'y with coupling pipe to clockwise.</p> <p>2. Connect the blue hose of the guage to the coupling pipe and the yellow hose to the vacuum pump.</p> <p>3. Open the blue guage lever and start the vacuum pump</p>
11	Vacuum		<p>1. Be vacuumed the cycle with pump.</p> <p>※ Time : 60~80min</p> <p>=> If the vacuum time is less than 60min, ref. COP & air coolong would be weak.</p>
12	Check		<p>1. Check the guage : -76cmHg</p> <p>※ If the cycle is not vacuumed, it would be leak.</p>
13	Adjusting the amounts of refrigerants (R-600a can)		<p>1. Check the amounts of R-600a can with scale and discharge the surplus ref.</p> <p>※ Discharging is surely done at the outdoor where is able to clear air.</p> <p>※ Tip of adjusting.</p> <ul style="list-style-type: none"> - Can total weight :160g(Can 75g+Ref. 85g) - Adapter : 145g <p>=> Total : 305g</p> <ul style="list-style-type: none"> - The amounts of charging : 79g <p>=> Discharging : 6g => Total : 299g</p>

NO.	SVC process	Image	Details
14	Connecting of coupling pipe & adapta		<ol style="list-style-type: none"> 1. Conect can adapter to the coupling pipe. 2. Charge the ref. with open lever slowly. <p>※ Refrigerant should never leak in the room.</p>
15	Charging		<ol style="list-style-type: none"> 1. On the power of refrigerator and then start to charge the ref. (10min) <p>※ Charge the ref. until going out the water vapour condensing on the can outlet.</p>
16	Leakage Test		<ol style="list-style-type: none"> 1. Check the leakage. <p>※ You must rework from Step.1 when the leakage is detected.</p>
17	Finish		<ol style="list-style-type: none"> 1. Clean and clear around the machinery room when the service is finished. 2. Assemble the machinery room cover.


Cabinet Compartment



NO	PART-CODE	PART NAME	SPEC.	Q'ty		
				T405..	T425..	T455..
1	-	ASSY CAB URT	BLACK / WHITE	1	1	1
2	3012929000	HINGE *T AS	RFP-340	1	1	1
3	3001427700	COVER *T AS	PP (WHITE)	1	1	1
4	3018125601	SWITCH H/BAR DR AS	SP101B-2D1	1	1	1
5	3001412200	COVER CAB HRNS	PP(WHITE)	1	1	1
	3001412220		PP(T/SILVER)			
6	30143HN060	PCB MAIN AS	V3 COMBI(AC FAN)	1	1	1
	30143HN090		V3 COMBI(DC FAN)			
7	3001416600	COVER M/PCB BOX AS	SPCC(WHITE)	1	1	1
	3001416630		SPCC(BLACK)			
8	3012928600	HINGE *M	PO, T3.2	1	1	1
9	3012928800	HINGE *U	PO, T3.2	1	1	1
10	3012104600	FOOT ADJ AS	PP+INSERT	2	2	2
11	3001442200	COVER CAB BRKT AS	PP (WHITE)	1	1	1
48	30143HJ210	PCB FRE LED AS	6-LED FR-4 120X20-1.6T	1	1	1
49	3015517200	WINDOW F LED *T	ABS	1	1	1




NO	PART-CODE	PART NAME	SPEC.	Q'ty		
				T405..	T425..	T455..
12	3010349300	BASE COMP AS	RFP-340	1	1	1
13	OPTION	CORD POWER AS	RFP-340	1	1	1
14	3956188C50	COMPRESSOR	LZ88CY (A+,EUROPE)	1	1	1
	3956158K50		YX58LHP5 2			
	3956141250		MD4A1Q-L1U			
15	3016002500	SPECIAL WASHER	SK-5 T0.8	4	4	4
16	3010101480	ABSORBER COMP AS	SPRING (R-600a)	4	4	4
	3010101600	ABSORBER COMP	NBR (R-134a)			
17	3018133020	SWITCH P RELAY AS	B60-120(LZ88CY)	1	1	1
	3018131810		YX58LHP5			
	3018132900		MD4A1Q-L1U			
18	3811402600	COVER RELAY	LZ88CY (A+,EUROPE)	1	1	1
	381140050		YX58LHP5			
	3811400503		MD4A1Q-L1U			
19	3011122800	CASE VAPORI AS	PP + TAPE ALUMINUM	1	1	1
20	3013202700	HOSE DRN B	PE	1	1	1
21	3015918110	MOTOR C AS	AC 230V/50HZ	1	1	1
	3015906850		DC 10V			
22	3010102100	ABSORBER C MOTOR	NR FRB -5350NT	1	1	1
23	3011802200	FAN	ABS OD3.17XD110	1	1	1
24	3014469600	PIPE WICON AS		1	1	1
25	3016808100	DRYER AS	SBS 12G	1	1	1
26	3001414000	COVER MACH RM AS	RFP-340	1	1	1
28	301640600	CAPACITOR RUN	400VAC /4uF(LZ88CY)	1	1	1
	3016405800		350VAC/4uF(YX58LHP5)			
	3016406100		400VAC /5uF(MD4A1Q-L1U)			



NO	PART-CODE	PART NAME	SPEC.	Q'ty		
				T405..	T425..	T455..
27	3017065200	EVA AS	R-134a	1	1	1
	3017068200		R-600a			
27-1	30127694100	HARNES D SENS	R-134a	1	1	1
	3012769400		R-600a			
27-2	3012822000	HEATER D AS	R-134a (GLASS)	1	1	1
	3012823000	HEATER SHEATH AS	R-600a			
29	3018927900	LOUVER F AS	RFP-341, AC FAN	1	1	1
	3018927950	LOUVER F AS	RFP-341, DC FAN	1	1	1
29-1	3018923700	LOUVER F A AS	LOUVER F A+SEAL	1	1	1
29-2	3018923800	LOUVER F B AS		1	1	1
29-2-1	3011836000	FAN AS	FAN+CLAMP	1	1	1
29-2-2	3015918210	MOTOR F AS	AC 230V/50HZ	1	1	1
	3015905350		DC 12V	1	1	1
29-2-3	3010664700	BRACKET FAN MOTOR	PP, T2.0	1	1	1
30	3011198000	CASE F C AS	CASE+WINDOW	1	1	1
31	3011197900	CASE F B AS	CASE+WINDOW	2	2	2
34	3010564910	CASE ICING AS	CRYSTAL	1	1	1
35	3001439500	COVER MULTI DUCT	ABS, RFP-326	1	X	X
	3001439600		ABS, RFP-346	X	1	X
	3001439700		ABS, RFP-356	X	X	1
35-1	3012764600	HARNES R SENS	NBC-K43-D21	1	1	1
36	3011197500	CASE VEGETB	GPPS	1	1	1
37	3001438700	COVER V/CASE AS	COVER+KNOB	1	1	1
38	3017851900	SHELF R INSERT AS	PP	3	3	3

Refrigerator & Freezer DOOR Compartment



NO	PART-CODE	PART NAME	SPEC.	Q'ty		
				T405..	T425..	T455..
39	30100A6210	ASSY R DR	BLACK	1	x	x
	30100A6310			x	1	x
	30100A6410			x	x	1
	30100A6200		WHITE	1	x	x
	30100A6300			x	1	x
	30100A6400			x	x	1
39-1	3012327700	GASKET R DR AS	RFP-326	1	x	x
	3012321200		RFP-346	x	1	x
	3012327800		RFP-356	x	x	1
40	3012037300	FIXTURE F PCB AS	WHITE	1	1	1
	3012037310		BLACK			
40-1	3012035800	FIXTURE F PCB	WHITE	1	1	1
	3012035810		BLACK			
40-2	30143HN170	PCB INTR FRONT AS	RFT-346	1	1	1
40-3	3012779300	HAARNES INTR FCP AS	RFT-326,346,356	1	1	1
41	30100A6300	ASSY F DR	WHITE	1	1	1
	30100A6310		BLACK			
41-1	3012321100	GASKET F DR AS	RFP-340	1	1	1
42	3019056100	POCKET DAIRY AS	RFP-341	1	1	1
43	3011190800	CASE EGG TRAY	GPPS	1	1	1
44	3019055900	POCKET BOTL	GPPS	1	1	1
45	3019059700	POCKET R *M	GPPS	1	1	1
46	3019055800	POCKET JUMBO	GPPS	1	1	1
47	3012532100	GUIDE BOTL POKT	HIPS	1	1	1

