




STYLING 494

AERIAL IN FM ANT SCART 1 SCART 2 AUDIO OUT VGA DVI-D PC AUDIO IN



IR Lightsensor
Red



STYLING 494.eps
050804

1abcde*	3139 177 82721	Top control	9a*	3139 177 85641	Connector plate
2a*	3139 121 28221	Vesa plate	9c*	3139 177 82781	Connector plate
2bcde*	3139 121 28051	Vesa plate			
3a*	3139 124 61451	Back plate	9e*	3139 177 71831	Connector plate
3bd*	3139 124 60731	Back plate	10a*	3139 128 77331	Metal stand
			10bd*	3139 128 77051	Metal stand
3ce*	3139 124 60721	Back cover	10ce*	3139 128 76981	Metal stand
4	Not applicable		11	Not applicable	
5a*	3139 177 85481	Rear cover	ace*	3139 120 01731	Word mark
5b*	3111 257 60441	Rear cover	bd*	3139 120 01651	Word mark
5c*	3111 257 60461	Rear cover		3139 124 43391	Light guide
				2422 076 00546	Aerial cable
5d*	3111 257 60452	Rear cover		3128 147 15821	Remote control RC1553801/01
5e*	3111 257 60472	Rear cover			
6a*	3139 177 85491	Front Cabinet pearl white silver 26"		3139 238 08141	Remote control RC19335019/01
6b*	3111 257 60791	Front cabinet 15"		3128 147 14871	Remote control RC19042008/01
6c*	3111 257 60421	Front cabinet 20"			
				2422 070 98151	Mains cord EU
6d*	3111 257 60412	Front cabinet 17"		9965 000 07586	Mains cord UK
6e*	3111 257 60432	Front cabinet 23"			
7a*	9322 212 69682	LCD screen LC260W01-A5K6	*a	26PF8946	
7b*	9322 207 48682	LCD screen LC150X02-A4	*b	15PF8946	
7c*	9322 211 50682	LCD screen LC201V02-A3K5	*c	20PF8846	
			*d	17PF8946	
7c*	9322 215 40682	LCD screen LC201V02-A3K9	*e	23PF8946	
7d*	9322 211 48682	LCD screen LC171W03-A4KC			
7e*	9322 214 13682	LCD screen QD23WL05			
8a*	2422 264 00506	Loudspeaker 8Ω 5W			
8b*	2440 257 30702	Loudspeaker 4Ω 5W			
8c*	2422 264 00519	Loudspeaker 8Ω 5W			
8d*	2422 264 00526	Loudspeaker 4Ω 5W			
8e*	2422 264 00518	Loudspeaker 8Ω 5W			