



BEFORE

- . Parts: Cover, TV
- . LOC NO : 154A





- . Parts: Supporter, Holder
- . LOC NO : 248A



AFTER

- . Parts: Cover, TV
- . LOC NO : 154A



- . Parts: Supporter, Holder
- . LOC NO : 248A



SVC Processing

1. Remove the both vegetable trays.



2. Remove the magic crisper while pushing it inside.



3. Lift and remove the cover assembly tv.



4. Lift and remove Magic Room covers while twisting the corner of the cover.



5. Remove the screw and lift up supporter holder



6. Replace old Cover, TV with the new Cover, TV.

7. When you assemble, assemble contrary to disassembly.

*When assembly the vegetable tray, insert the boss to the hole like down picture.

