


Service Service Service


32PF9730/10
32PF9830/10
37PF9730/10
37PF9830/10
42PF9730/10
42PF9830/10
42PF9830/69
42PF9830/93
42PF9986/69
42PF9996/37

Styling Sheet


CONNECTOR BOTTOM (EU & AP Version)




CONNECTOR BOTTOM (USA Version)





FRONT CONTROLS



TOP CONTROLS



SIDE I/O



TOP UPDATE_2006_22_A_1Sp.eps
020606

31 August 2006

Top_Update_2006_25_B_RT.fm

©Copyright 2006 Philips Consumer Electronics B.V. Eindhoven, The Netherlands.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.

Safety regulations require that the set is restored to its original condition and that parts which are identical with those specified are used.



PHILIPS

Mechanical Parts List

Top Update

Pos. number	Item number	12NC	Description	32PF9830/10	37PF9830/10	42PF9730/10	42PF9830/10	42PF9830/69	42PF9830/93	42PF9996/37	42PF9986/69	32PF9730/10	37PF9730/10
1	0006	310430811791	Front 42"			x	x	x	x		x		
1	0006	310430811801	Front 32"	x								x	
1	0006	310430811811	Front 37"		x								x
1	0019	310430426562	Cabinet 32"									x	
1	0019	310432838231	Cabinet 37"		x								
1	0019	310430426572	Cabinet 37"										x
1	0019	310432838212	Cabinet 42"			x	x	x	x				
1	0152	310430811731	Inner front 42"			x	x	x	x	x	x		
1	0152	310430811751	Inner front 32"	x								x	
1	0152	310430811771	Inner front 37"		x								x
1	0154	310430811741	Outer front 42"			x	x	x	x	x	x		
1	0154	310430811761	Outer front 32"	x								x	
1	0154	310430811781	Outer front 37"		x								x
3	0050	310430012381	Wordmark	x	x	x	x	x	x	x	x	x	x
4	0041	310430426541	Light guide							x	x		
4	0041	310430429181	Light guide	x	x	x	x	x	x			x	x
5	1004	932221111682	LCD display 42" LC420W02-A4K3 (LGPH)					x	x	x	x		
5	1004	932222639682	LCD display 42" LC420W02-A6 (LGPH)			x		x	x				
5	1004	932222658682	LCD display 32" LQ315T3LZ23 (Sharp)	x									
5	1004	932222848682	LCD display 37" LQ370D3LZ13 (Sharp)		x								x
5	1004	932222899682	LCD display 42" LC420WU1-SL01 (LGPH)				x						
5	1004	932223003682	LCD display 32" LC320W01-SL06 (LGPH)									x	
5	1005	310432836291	LCD PSU									x	
5	1005	310432838021	LCD PSU										x
7	5212	310413002901	Loudspeaker monolith	x									
7	5212	310413002931	Loudspeaker monolith		x								
7	5212	310413003511	Loudspeaker monolith							x	x		
7	5212	310413003571	Loudspeaker monolith									x	x
7	5212	310413003591	Loudspeaker monolith			x	x	x	x				
8	0052	310430815701	Top control mains knob									x	x
8	0053	310430429281	Top control knob frame									x	x
8	0054	310430426481	Top control bottom cover									x	x
8	1014	310432841561	Top control									x	x
8	1114	310432830781	Top control							x	x		
8	1114	310432841561	Top control no blue led's					x					
8	1114	310432841701	Top control	x	x	x	x		x			x	x
9	0205	310430126026	Side AV Bracket									x	
9	0205	310430126394	Side AV Bracket										x
9	0205	310430426531	Side AV Bracket	x		x	x	x	x	x	x	x	x
9	0205	310432830791	Side AV Bracket		x					x	x		
9	1116	310432828883	Side AV					x					
9	1116	310432830791	Side AV	x	x	x	x		x	x	x	x	x
10	0046	310413003151	Center plate								x		
10	0046	310413003171	Center plate (US)							x			
10	0046	310413003541	Center plate	x								x	
10	0046	310413003551	Center plate										x
10	0046	310413003561	Center plate			x	x	x	x				
10	0046	312212167193	Center plate									x	
10	5215	244125710001	Loudspeaker 6R 15W									x	x
11	0206	310430811881	Chassis frame 42"							x	x		
11	0206	310430814964	Chassis frame 32"	x									
11	0206	310430814981	Chassis frame 42"			x	x	x	x				
11	0206	310430815284	Chassis frame 37"		x								x
11	0206	310430814967	Chassis frame 32"									x	
12	0164	310430813162	Fixation bracket 32"									x	
12	0164	310430813172	Fixation bracket 37"										x
13	0037	310430813531	Connector plate									x	
13	0037	310430816071	Connector plate										x
13	0165	310430125512	Connection bracket									x	
14	0070	310430811911	SSB top shielding	x	x	x	x	x	x			x	x
14	0070	310430811931	SSB top shielding							x	x		
16	0160	310430812071	Mushroom	x	x	x	x	x	x	x	x	x	x
17	0071	310430811921	SSB bottom shielding	x	x	x	x	x	x			x	x
17	0071	310430811941	SSB bottom shielding							x	x		
18	0010	310432830751	Rear cover 42"								x		
18	0010	310432838181	Rear cover 32"	x									x

Mechanical Parts List

Top Update				32PF9830/10	37PF9830/10	42PF9730/10	42PF9830/10	42PF9830/69	42PF9830/93	42PF9996/37	42PF9986/69	32PF9730/10	37PF9730/10
18	0010	310432838191	Rear cover 37"		x								x
18	0010	310432838241	Rear cover 42"			x	x	x	x				
18	0010	310432841011	Rear cover 42" (US)							x			
19	1175	272217100291	Ambient light unit right 32"	x									
19	1175	272217100293	Ambient light unit right 37"		x							x	x
19	1175	272217100297	Ambient light unit right 42"			x	x	x	x				
19	1176	272217100294	Ambient light unit left 32"	x									
19	1176	272217100295	Ambient light unit left 37"		x							x	x
19	1176	272217100296	Ambient light unit left 42"			x	x	x	x				
20	0156	310430811841	Backplate 42"			x	x	x	x	x	x		
20	0156	310430811861	Backplate 37"		x								x
20	0156	310430814471	Backplate 32"	x								x	
12+15	0164	310430813151	Fixation bracket 42"			x				x	x		
12+15	0164	310430813152	Fixation bracket 42"				x	x	x		x		
12+15	0164	310430813161	Fixation bracket 32"	x									
12+15	0164	310430813171	Fixation bracket 37"		x								
	0094	310430124731	Wallmount bracket	x	x	x	x	x	x		x	x	x
	0115	310431571531	Soundplate									x	x
	0151	310430427793	Card reader base									x	x
	0152	310430427801	Card reader cover									x	x
	0153	310430427812	Card reader top									x	x
	0163	312212436081	Daylight filter									x	x
	0165	310430125111	Topconnection bracket	x									
	0180	310432835421	Cardreader	x	x	x	x	x	x			x	x
	0212	310430815031	U-profile for rear cover	x	x	x	x	x	x				
	0212	310430819511	Stand upright part									x	x
	0213	310430815011	Stand glass + swivelmotor 32"	x									
	0213	310430815021	Stand glass + swivelmotor 37" 42"		x	x	x	x	x				
	0213	310430819491	Stand base part									x	
	0213	310430819501	Stand base part										x
	0261	310430428851	Locking part LVDS	x	x	x	x	x	x			x	x
	1850	242254900487	Remote control RC4310/EU	x	x	x	x	x	x			x	x
	1850	312814714431	Remote control RC4302/01							x	x		
	8191	242207098259	Mainscord EU									x	x
	8191	462200150945	Mainscord EU									x	x
	8192	242207098251	Mainscord UK									x	x
	8192	310431105362	Mainscord UK										x
	8192	462200400393	Mainscord UK									x	x
	8250	310431111061	LVDS cable										x