




STYLING 560



STYLING 560 eps
150805

1ac*	0006	3104 328 40551	Front assy 42"	16af*	1004	9322 226 37682	Screen PDP 42" S42SD-YD07
1eg*	0006	3104 328 40861	Front assy 42"	16e*	1004	9322 224 88682	Screen PDP 42" PDP42V7A062
1fh*	0006	3104 328 40851	Front assy 42"	16g*	1004	9322 226 61682	Screen PDP 42" PDP42V7K062
1i*	0006	3104 328 42191	Front assy 42"	16dj*	1004	8204 000 78201	Screen PDP 50" S50HW-XD04
1b*	0006	3104 328 40561	Front assy 50"	16bk*	1004	9322 226 54682	Screen PDP 50" S50HW-XD04
1d*	0006	3104 328 42181	Front assy 50"	17	0240	3104 308 13652	Right shielding frame 42"
1j*	0006	3104 328 42201	Front assy 50"	17	0240	3104 308 13712	Right shielding frame 50"
1k*	0006	3104 328 39961	Front assy 50"	18abefgh*	1014	3104 328 39561	Side control (LC4.9)
2aefgh*	0224	3104 328 40771	Cover left 42"	18cdijk*	1014	3104 328 36671	Side control (Jaguar)
2c*	0224	3104 328 40781	Cover left 42"	19	0041	3104 304 28141	Light guide 42"
2i*	0224	3104 328 40791	Cover left 42"	19	0163	3122 124 36081	Light guide 50"
2b*	0224	3104 328 40811	Cover left 50"	20acefgh*	0227	3104 304 28241	Cover right 42"
2d*	0224	3104 328 40821	Cover left 50"	20i*	0227	3104 328 40801	Cover right 42"
2jk*	0224	3104 328 40831	Cover left 50"	20bd*	0227	3104 304 28301	Cover right 50"
3	0237	3104 308 13632	Upper shielding frame 42"	20jk*	0227	3104 304 40841	Cover right 50"
3	0237	3104 308 13692	Upper shielding frame 50"	cdijk*	0097	3104 308 14591	Vesa plate 42" (Jaguar)
4	5213/5214	2441 257 30020	Loudspeaker L/R	abefgh*	0097	Not applicable	Vesa plate 42"
5	0239	3104 308 13642	Left shielding frame 42"	abef	1850	3139 238 10231	Remote control RC1683701/01 (LC4.9)
5	0239	3104 308 13702	Left shielding frame 50"	gh*	1850	3139 238 10301	Remote control RC1683701/01 (LC4.9x AB)
6abcdefghk	0058	3104 308 13781	Audio standby plate 42" + 50"	cd*	8195	3139 238 11631	Remote control RC4345/01B (BP2.3)
Gij*	0050	Not applicable	Audio standby plate 42" + 50" (BP2.2 only)	ij*	1850	2422 549 00635	Remote control RC4318/US (BP2.2)
7	0164	3104 308 14712	Fixation bracket 42"	k*	1850	2422 549 00486	Remote control RC4308/US (BP2.1)
7	0164	3104 308 14722	Fixation bracket 50"	abcde*	0211, 0212	3104 308 14601	Upright stand
8ab*	1116	3104 328 40501	Side I/O (LC4.9A only)	abcdefghj*	0212, 0213	3104 308 14621	Base stand
8cd*	1016	3104 328 28892	Side I/O	k*	0213	3104 308 15061	Stand
8efghijk*	1016	3104 328 28881	Side I/O	cdijk*	8195	4622 001 50945	Mains cord /79 /98 /10
9afh*	0007	3104 304 90511	Glass plate 42"	*a	42PF7320/79/98	4622 004 00393	Mains cord /79 /98 /10
9ci*	0007	3104 304 90571	Glass plate 42"	*b	50PF7320/79/98	2422 070 00015	Mains cord /79
9efg*	0007	3104 304 90501	Glass plate 42"	*c	42PF7320A/37	2422 070 00064	Mains cord /12
9bdjk*	0007	3104 304 90551	Glass plate 50"	*d	50PF7320A/37	2422 070 98258	Mains cord UK
10	0238	3104 308 13622	Lower shielding frame 42"	*e	42PF5320/10	2422 070 00054	Mains cord US
10	0238	3104 308 13682	Lower shielding frame 50"	*f	42PF7320/10		
11acefghi*	0231	3104 308 14411	SSB plate 42"	*g	42PF5520D/10		
11bdk*	0231	3104 308 14581	SSB plate 50"	*h	42PF7520D/10		
11j*	0231	Not applicable	SSB plate 50"	*i	42PF9630A/37		
12	0160	3104 308 12071	Mushroom assy	*j	50PF9630A/37		
13a*	0009	3104 308 14531	Back cover 42"	*k	50PF9830A/37		
13ef*	0009	3104 308 14151	Back cover 42"				
13gh*	0009	3104 308 15411	Back cover 42"				
13ci*	0009	3104 308 15621	Back cover 50"				
13dj*	0009	3104 308 15641	Back cover 50"				
13k*	0009	3104 308 14241	Back cover 50"				
13b*	0009	3104 308 14231	Back cover 50"				
14abef*	0070	3104 308 14741	Top shielding				
14cdgijk*	0070	3104 308 13411	Top shielding				
14h*	0070	3139 267 16311	Top shielding				
15abcdfgh*	0071	3104 308 12321	Bottom shielding				
15dijk*	0071	3104 308 13422	Bottom shielding				
16chi*	1004	9322 225 38682	Screen PDP 42" S42AX-YD01				