

CAUTION
INVISIBLE LASERRADIATION WHEN OPEN:
DO NOT STARE INTO BEAM

MECHANICAL PARTSLIST

201	4822 444 40332	FRONT ASSY /01/02/04/05
201	4822 444 40345	FRONT ASSY /06
202	4822 459 10747	WORDMARK /01/02/04/05
202	4822 459 10887	WORDMARK /06
203	4822 450 61474	LENS ASSY /01/02/04/05
203	4822 450 61491	LENS ASSY /06
204	4822 444 30421	TRAY COVER ASSY /01/02/04/05
204	4822 444 30425	TRAY COVER ASSY /06
206	4822 321 10522	MAINS CORD SET /05B
207	4822 321 10457	MAINS CORD SET /01B/02B
208	4822 321 10445	MAINS CORD SET /06B
208	4822 321 10492	MAINS CORD SET /04B
209	4822 323 20182	FIBER CABLE
211	4822 532 51756	
212	4822 321 22603	
213	4822 218 10304	IR TRANSMITTER /01B/02B/04B/05B
213	4822 218 10308	IR TRANSMITTER /06B
214	4822 410 60415	POWER KNOB
216	4822 410 60414	KNOB UNIT
217	4822 410 60411	KNOB UNIT ASSY /01/02/04/05
217	4822 410 60463	KNOB UNIT ASSY /06
218	4822 492 52094	
219	4822 402 61252	
221	4822 444 50603	
222	4822 325 50176	
223	4822 325 50177	
224	4822 466 92251	
226	4822 492 70332	
227	4822 444 30417	
228	4822 444 60568	
229	4822 466 92257	
231	4822 402 61207	
232	4822 520 40177	
233	4822 530 80503	
234	4822 402 61253	
234	4822 402 61253	
236	4822 358 10115	
237	4822 528 90638	
238	4822 528 81329	
239	4822 444 30404	
241	4822 492 52123	
242	4822 402 50276	
243	4822 444 60655	INSULATION COVER /01/02/04/05
243	4822 444 60666	INSULATION COVER /06
244	4822 492 32883	

246	4822 528 90639	252	4822 466 61587
247	4822 691 30209	254	4822 535 80806
248	4822 402 61196	256	4822 444 60653
249	4822 492 51902	257	4822 444 50621
251	4822 361 21258	258	4822 444 30404

COVER BACKPLATE

EVA.00849
T07-937