

Spare part list

Model ADP 2966 WHM
Service No. 854296610590
Version 854296610590


Pos. No. 12NC Code	Description	Pos. No. 12NC Code	Description
003 0 4812 440 19594	Traverse	331 0 4812 413 59028	Knob program cpl. WH
004 0 4812 440 18952	Drip tray assy	332 0 4812 410 28669	Button WH
004 1 4812 401 18402	Holder	332 1 4812 410 28671	Button WH
011 0 4812 505 18357	Foot short	400 0 4812 361 58126	Motor + spraypump cpl.
022 0 4812 440 18951	Side panel left	405 0 4812 360 18371	Spray pump
022 1 4812 440 18949	Side panel right	405 1 4819 515 28158	Gasket
024 0 4812 440 19463	Panel, rear	420 0 4812 121 18132	Capacitor
030 0 4812 440 19755	Table top WH	421 0 4812 121 18161	Interf.filter
034 0 4812 404 78237	Spacer	430 0 4812 360 18357	Pump,draining
034 1 4812 404 78242	Fastener table top	430 1 4812 466 68506	Shaft seal
040 1 4812 417 18774	Hinge left	442 0 4812 361 18196	Blower cpl.
040 2 4812 417 18773	Hinge right	450 0 4812 259 28684	Heating element
040 3 4812 417 18923	Protector f.door (set)	480 0 4812 321 28394	Cable harness set
044 0 4812 492 38358	Spring f.door	480 1 4812 321 28371	Cable
047 0 4812 404 48591	Brake f.door	480 3 4812 401 18418	Protector f.wiring
047 1 4812 401 18397	Band,brake	480 4 4812 321 28387	Cable
047 2 4812 404 68023	Hook	490 0 4819 321 18136	Cable,mains 2m SA
053 0 4812 440 88888	Plinth WH	490 1 4812 321 28367	Strain relief
053 4 4812 440 88932	Plinth rounded WH	521 0 4812 214 78431	Control board (CB)
065 0 4812 466 48051	Insulation	531 0 4812 273 18055	Switch waterhardness
103 0 4812 440 19756	Door outer WH from 00/32	531 1 4812 273 18056	Wheel,fingertip
103 0 4812 440 19833	Door outer WH to 00/32	571 3 4812 281 28363	Valve f.zone-washing
103 2 4812 440 19778	Corner piece set	575 0 4812 281 28361	Regen.valve
120 0 4812 440 19456	Door,inner	583 0 4812 271 28407	Switch diaphragm
120 1 4812 440 18969	Batten	616 0 4812 281 18047	Contact,reed salt
130 0 4812 417 58361	Tilt lock cpl. wh	616 1 4812 271 58161	Contact,reed rinsing agent
131 0 4812 401 18416	Hook lock	620 0 4812 218 38095	User board (DUB)
191 0 4812 466 68564	Gasket door	623 0 4812 271 38356	Microswitch
191 3 4812 466 68533	Gasket	633 0 4812 271 38355	Microswitch door
192 0 4812 466 68467	Gasket, door lower	680 0 4812 418 68155	Combidosage
241 0 4812 458 18912	Basket upper straight	680 1 4812 466 68495	Gasket
241 1 4812 458 18324	Holder cups right wh	681 1 4812 466 68497	Gasket
241 3 4812 528 88068	Wheel,basket upper (set)	681 2 4812 440 18975	Flap
241 4 4812 458 18984	Holder dishes	682 0 4812 466 68496	Gasket
241 5 4812 535 78043	Bearing	691 0 4812 282 68012	Feeler NTC
241 6 4812 458 18979	Holder glasses	692 1 4812 209 88001	Sensor turbidity
241 7 4812 404 48683	Hoop	700 0 4812 530 28804	Hose, inlet aqua stop 4,2m
241 8 4812 466 68553	Spacer cap set	700 0 4812 530 28848	Hose, inlet aqua stop 2m
242 0 4812 458 18974	Basket lower cpl.	700 1 4812 480 48095	Sieve
242 1 4812 528 88069	Wheel,basket lower	700 2 4812 466 68628	Gasket
242 4 4812 466 48059	Fixation	701 1 4812 310 18153	Yoke clamp set
242 6 4812 458 18977	Support plate left	710 0 4812 418 68151	Monoblock
242 7 4812 458 18978	Support plate right	710 2 4819 310 38536	Threaded ring
243 0 4812 458 18272	Basket cutlery	710 3 4819 466 69562	Gasket set
243 5 4819 310 39859	Cutlery basket KIT	714 0 4812 462 78993	Threaded cap
243 6 4812 458 18996	Grille	714 2 4812 440 18963	Cabinet non-return flap
261 0 4819 462 38271	Rail telescope, inner	716 0 4812 418 68147	Reg.dosage
261 1 4819 404 48819	Cap rail	716 1 4812 466 68475	Gasket
261 2 4812 462 78995	Cap rail ahead	716 2 4812 462 78994	Cover
263 0 4819 520 18013	Ball cage cpl.	721 1 4812 360 68061	Spray arm lower. cpl.
263 1 4812 520 48001	Ball Niro 8 D	721 2 4812 466 68491	Gasket 25x2,3B
265 0 4812 404 48637	Basket adjustm. cpl.	721 3 4812 466 68558	Gasket 30x3,0
265 2 4812 404 48638	Grip basket adjustment	721 4 4812 440 19455	Flange
303 1 4812 460 38092	Plate,handle WH	722 0 4812 360 68044	Spray arm upper
322 0 4812 453 70883	Insert panel	722 2 4812 360 68056	Hub upper straight cpl.

Spare part list

Model ADP 2966 WHM
Service No. 854296610590
Version 854296610590

Pos. No.	12NC Code	Description
723 0	4812 360 68049	Spray arm ceiling
723 1	4819 310 39831	Kit
726 0	4812 530 28786	Tube
726 1	4812 530 28787	Tube
726 2	4812 505 18358	Nut
726 3	4812 466 68512	Gasket
726 4	4812 462 79633	Centering
743 0	4812 530 48134	Air guide
743 1	4812 530 28102	Hose, inlet
743 2	4812 440 19526	Air guide lower
743 3	4812 505 18364	Nut
743 4	4812 281 38001	Valve disk
743 5	4812 466 98934	Disc
743 7	4812 466 68514	Gasket
751 0	4812 418 18205	Water collector
751 1	4819 310 39826	Water guide service kit
755 0	4812 530 28868	Bend
755 2	4812 530 48148	Tray,leak
756 0	4812 360 58099	Floater
761 0	4812 480 58082	Sieve fine
761 2	4812 418 18204	Cover sieve
762 0	4812 480 58084	Microfilter
763 0	4812 480 58083	Sieve coarse
781 0	4812 530 28737	Hose,draining
781 1	4819 530 28286	Sleeve hose
781 2	4819 492 68405	Clip f.non-return valve
781 3	4812 281 28364	Flap non-return
783 1	4812 530 28806	Hose connection
783 5	4812 530 28851	Distributor
783 6	4812 530 28796	Hose 10x3x180+10
791 0	4812 532 68067	Gasket
791 2	4812 530 58093	Gasket
791 4	4812 466 68503	Gasket
791 5	4812 466 68504	Gasket
794 1	4819 530 58032	Gasket 20x2,5
901 0	4822 401 10492	Clamp,hose 14-24 mm
901 1	4812 401 18424	Strap 050,0
901 2	4812 401 18157	Strap 32-50/9 C61
901 5	4812 401 48573	Strap 028,6
901 7	4812 401 18427	Strap 031,6
904 2	4812 462 79635	Cover WH 3,5x5
910 0	4812 502 18398	Screw,selftap ST4,2x9,5
910 1	4812 502 18394	Screw 3,5x14-H
910 2	4812 502 18363	Screw 4,0x12-H
910 3	4812 502 18389	Screw NIRO A2
910 4	4812 502 18385	Screw M3,5x8-T15M
910 5	4812 502 18393	Screw 3,5x9-1 Tx15
910 7	4812 502 18397	Screw INOX A2 M 5X12
910 9	4812 502 18446	Screw 3,5x16
964 0	4812 466 68536	Gasket housing ri/le
964 1	4812 466 68469	Gasket housing upper
993 0	4819 530 29028	Bow
993 5	4822 532 80216	Funnel salt

Exploded view



Exploded view

