

Spare part list

Model **ARC 5550**
Service No. **850155510000**
Version **850155510000**

Pos. No.	12NC Code	Description
001 1	4812 466 99027	Traverse
001 2	4812 525 18014	Guide
002 0	4812 464 18098	Cover
002 1	4812 157 48001	Spacer
011 0	4812 462 18249	Adjusting screw
012 0	4812 528 78062	Roller
012 1	4812 535 78077	Pin
040 0	4812 417 19231	Hinge, upper left
040 1	4812 417 19232	Hinge, upper right
040 2	4812 417 19139	Hinge, middle
040 3	4812 526 48142	Washer
040 4	4812 417 19115	Hinge, lower
101 0	4812 416 19258	Door, freezer
104 0	4812 416 19257	Door, refriger.
105 0	4812 532 88034	Bushing
105 1	4812 532 88033	Sleeve
105 2	4812 532 88048	Sleeve, left
152 0	4819 418 79724	Door, dairy upper
152 1	4812 418 28439	Flap f. door dairy
152 2	4812 418 28624	Shelf
152 3	4812 418 28606	Bottle shelf
152 4	4812 418 28426	Separator
156 0	4812 418 28471	Icecube, tray
156 1	4812 418 28427	Holder, eggs
176 0	4812 459 18218	Nameplate
241 0	4812 418 79962	Crisper
242 0	4812 418 68301	Drawer
242 1	4812 418 68299	Drawer
242 2	4812 418 48688	Cover, basket
242 3	4812 418 48689	Cover, basket
244 0	4812 458 19187	Rack
246 0	4812 462 28454	Tray
246 1	4812 462 28453	Tray
255 0	4812 450 88214	Shelf glass
255 1	4812 450 88222	Glass shelf
301 0	4812 452 28591	Panel, control
301 1	4812 440 98193	Cover, thermost.
301 2	4812 462 28556	Cover
301 3	4812 462 28557	Cover
331 0	4812 412 18035	Knob thermostat
402 0	4812 360 38863	Compressor HQY 11 AA
402 1	4812 418 78958	Tray, compressor
480 0	4812 321 78176	Cable harness
491 0	4812 462 28261	Cover
491 1	4812 290 88084	Connect. block
554 0	4812 282 38134	Thermostat, K59 L2719
614 0	4812 280 38047	PTC-Unit K100ZF5(ZF5)
651 0	4819 134 88135	Lamp 220V 15W
651 1	4812 440 98138	Housing Lamp
652 0	4812 255 28015	Holder, lamp
655 0	4812 271 58178	Switch, WP20K
656 0	4812 460 98066	Cover f. lamp
740 0	4812 511 48314	Condenser
740 1	4812 462 28448	Holder
746 1	4812 466 28139	Holder evap. left

Pos. No.	12NC Code	Description
746 2	4812 462 28447	Holder evap., right
746 3	4812 460 98054	Panel
746 4	4812 460 98055	Panel
764 0	4819 526 48527	Dryer
781 0	4812 171 58001	Hose
781 1	4812 171 58002	Overload cond.
783 0	4819 526 43046	Tube
904 0	4812 462 28508	Cover, screw
904 1	4812 532 88029	Stopper
904 2	4812 226 08003	Plug
904 3	4812 226 08008	Cover I
904 4	4812 226 08009	Cover II
904 5	4812 226 08007	Plug
910 0	4812 502 38357	Screw
910 1	4812 502 38356	Screw

Exploded view

