


EXPLODED VIEW / Drawing 1

MECHANICAL PARTS

- | | | |
|------|----------------|--|
| 414 | 4822 492 52397 | SPRING REC.LEVER |
| 416 | 4822 529 10257 | DAMPER CASS.DOOR |
| 417 | 4822 535 93535 | AXLE, RECORDER KEYS |
| 418 | 4822 492 42709 | SPRING,OPEN CASSDOOR |
| 419 | 4822 498 10515 | CARRYING HANDLE |
| 421 | 4822 492 71653 | SPRING, OPEN CD DOOR |
| 424 | 4822 303 30298 | TELESCOPIC ANTENNA |
| 426 | 4822 460 11019 | FOIL ORNAMENT. RIGHT (AZ8262) |
| 426 | 4822 460 11021 | FOIL ORNAMENT. RIGHT (AZ8267) |
| 427 | 4822 218 10542 | REMOTE CONTROL RH5012/00 (AZ8267) |
| 428 | 4822 492 51733 | SPRING BATT.INTERCON |
| 429 | 4822 321 10249 | MAINS CORD EUROPE IEC |
| 429 | 4822 321 10882 | MAINS CORD USA POL. |
| 429 | 4822 321 11074 | MAINS CORD UK |
| 431 | 4822 462 40683 | FOOT RUBBER |
| 432 | 4822 290 80313 | CONTACT PLATE BATT.+ |
| 433 | 4822 492 51961 | SPRING, BATTERY - |
| 434 | 4822 423 41255 | BATTERY LID |
| 451 | 4822 411 62002 | KNOB EQUALIZER |
| 1000 | 4822 240 30739 | LOUDSPEAKER, 4" 4OHM |

continued on next page (chapter 9 - 2)



● ۱۰۰٪