


5-3. MAIN BOARD SECTION



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	3-230-493-01	GEAR (DRIVE SHAFT)		107	1-777-246-41	CORD (WITH CONNECTOR) (ANTENNA)	
102	3-230-444-01	GUIDE (DRIVE SHAFT)		108	1-790-375-32	CORD (WITH CONNECTOR) (SUB OUT (MONO))	
103	3-040-692-01	RING, CE TYPE RETAINING		F901	1-532-877-11	FUSE (BLADE TYPE) (AUTO FUSE) 10A	
104	3-045-721-01	SHAFT, DRIVE		TUX501	A-3220-887-A	TUNER UNIT (TUX-030)	
105	3-376-464-11	SCREW (+PTT 2.6X6), GROUND POINT		#2	7-685-792-09	SCREW +PTT 2.6X6 (S)	
106	A-3274-933-A	MAIN BOARD, COMPLETE (US,CND)		#6	7-685-795-09	SCREW +PTT 2.6X12 (S)	
106	A-3274-934-A	MAIN BOARD, COMPLETE (AEP,UK,E)		#7	7-685-134-19	SCREW +P 2.6X8 TYPE2 NON-SLIT	