

SECTION 6 REPAIR PARTS LIST

6-1. EXPLODED VIEWS

NOTE:


- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.

- Abbreviation
AUS: Australian model
JE: Tourist model
CND: Canadian model
CN: Chinese model
HK: Hong Kong model

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

6-1-1. OVERALL SECTION



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
1	3-989-735-11	SCREW(M1.7), LOCK ACE, P2		6	3-742-854-21	LID, BATTERY CASE (FOR RMT-809)(PC4E)	
2	3-062-213-01	COVER, MIC		7	3-052-290-11	COVER, BATTERY TERMINAL	
3	3-724-511-51	SHOE, ACCESSORY		8	3-062-110-02	COVER, JACK (PC5)	
4	3-056-624-01	LOCK ACE, +K SCREW (M2)		8	3-062-110-11	COVER, JACK (PC5E:AEP,UK)	
5	1-475-141-31	REMOTE COMMANDER (RMT-809)(PC4E)		8	3-062-110-21	COVER, JACK (PC5E:E,HK,AUS,CN,JE)	
5	1-475-950-21	REMOTE COMMANDER (RMT-811)(PC5)		8	3-062-110-31	COVER, JACK (PC4E)	
5	1-475-950-31	REMOTE COMMANDER (RMT-812)(PC5E)		9	3-989-735-31	SCREW(M1.7), LOCK ACE, P2	
6	3-053-056-01	LID, BATTERY CASE (FOR RMT-811, 812) (PC5/PC5E)		10	X-3950-754-1	CAP ASSY, LENS	