

SECTION 6 REPAIR PARTS LIST


6-1. EXPLODED VIEWS

NOTE:

- XX, -X mean standardized parts, so they may have some differences from the original one.
- Items marked "※" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Abbreviation
HK : Hong Kong model
AUS : Australian model
JE : Tourist model
CN : Chinese model

The components identified by mark $\triangle$ or dotted line with mark $\triangle$ are critical for safety. Replace only with part number specified.

6-1-1. OVERALL SECTION



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
1	X-3951-161-1	GRILLE ASSY, MICROPHONE		9	A-7074-651-A	FP-273 BOARD, COMPLETE	
2	3-065-310-01	RING, RUBBER		10	3-065-327-01	CUSHION (MI)	
3	3-067-347-01	MI SCREW M2 (H)		11	3-742-854-01	LID, BATTERY CASE (FOR RMT-814)	
4	X-3949-376-1	CAP(N) ASSY, LENS		12	1-475-141-61	REMOTE COMMANDER (RMT-814)	
5	X-3951-207-1	PANEL ASSY (P), FRONT		13	3-065-326-01	CABINET (UPPER)	
6	3-066-722-01	CUSHION, SENSOR		14	3-065-325-01	LID(BT), CPC	
7	3-948-339-61	TAPPING		15	3-065-567-01	TAPPING (M1.7)	
8	A-7074-726-A	SI-028 (M) BOARD, COMPLETE (TRV230E/TRV235E/TRV325E/TRV330E)		16	3-066-720-01	CUSHION (SI)	
8	A-7074-812-A	SI-029 (M) BOARD, COMPLETE (TRV430E/TRV530E)		MIC901	1-542-312-11	MICROPHONE (Lch)	
				MIC902	1-542-312-11	MICROPHONE (Rch)	