


Model No. : DMC-GM1K/GM1W Frame and Casing Section




Model No. : DMC-GM1K/GM1W Camera Lens Section (1)

H-FS12032




Model No. : DMC-GM1K/GM1W Camera Lens Section (2)


H-H020A



Model No. : DMC-GM1K/GM1W Packing Parts and Accessories Section (1)



Model No. : DMC-GM1K/GM1W Packing Parts and Accessories Section (2)



Model No. : DMC-GM1K/GM1W Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		1	VEP56191B	MAIN P.C.B.	1	E.S.D. EG,EC,EF,EB,GC
		1	VEP56191A	MAIN P.C.B.	1	E.S.D. P, PC, PU, EE, GH, GT, GK, GN, GD
		2	VEP50167A	TOP P.C.B.	1	(RTL) E.S.D.
		3	VEP50168A	AF LED P.C.B.	1	E.S.D.
		4	VMP0H39	TRIPOD	1	
		5	VMB4768	JACK DOOR SPRING	1	
		6	VMB4785	BATTERY OUT SPRING	1	
		7	VGQ1K26	JACK CAM PIECE	1	
		8	VGU0Q87	BATTERY LOCK KNOB	1	(-K, -S)
		8	VGU0R04	BATTERY LOCK KNOB	1	(-W)
		8	VGU0R06	BATTERY LOCK KNOB	1	(-D)
		9	VKF5270	JACK DOOR	1	(-K, -S)
		9	VKF5271	JACK DOOR	1	(-W)
		9	VKF5274	JACK DOOR	1	(-D)
		10	VMB4304	BATTERY LOCK SPRING	1	
		11	VMB4767	BATTERY DOOR SPRING	1	
		12	VMP0H32	BATTERY CASE PLATE	1	
		13	VMS8413	BATTERY DOOR SHAFT	1	
		14	VMS8414	JACK DOOR SHAFT	1	
		15	VYF3566	BATTERY DOOR UNIT	1	(-K, -S)
		15	VYF3567	BATTERY DOOR UNIT	1	(-W)
		15	VYF3568	BATTERY DOOR UNIT	1	(-D)
		16	VYK6R35	BATTERY FRAME UNIT	1	(-K, -S)
		16	VYK6R36	BATTERY FRAME UNIT	1	(-W)
		16	VYK6R37	BATTERY FRAME UNIT	1	(-D)
		17	VYK6R38	FLASH UNIT	1	(-K)
		17	VYK6R39	FLASH UNIT	1	(-S, -W, -D)
		17-1	VKM0J32	FLASH CASE TOP	1	(-K)
		17-1	VKM0J33	FLASH CASE TOP	1	(-S, -W, -D)
		18	VYK6R40	FLASH BASE UNIT	1	
		24	VYQ8965	SPEAKER UNIT	1	
		27	L0CBAY000186	MICROPHONE UNIT	1	
		28	VGL1474	AF WINDOW	1	
		29	VGL1475	POWER LED PANEL	1	
		32	VGQ1R49	MODE DIAL ROTOR	1	
		35	VGQ1S03	MIC CUSHION	1	
		36	VGQ1S03	MIC CUSHION	1	
		37	VMB4774	POWER DIAL SPRING	1	
		42	VMB4784	FOCUS DIAL SPRING	1	
		45	VMD6196	CLICK BALL	1	
		46	VMD6196	CLICK BALL	1	
		47	VMP0H46	TOP EARTH PLATE	1	
		48	VMP0H47	AUDIO FPC FIX PLATE	1	
		50	VMT2027	MIC DAMPER	1	
		51	VMT2027	MIC DAMPER	1	
		52	VWJ2447	MAIN-TOP FPC	1	
		58	VYK6S96	TOP CASE UNIT	1	(-K)
		58	VYK6S97	TOP CASE UNIT	1	(-S, -W, -D)
		59	N4ECY25Y0002	BUTTON BATTERY	1	(B8001)
		61	VEK0V04	REAR OPERATION UNIT	1	(-K, -S)
		61	VEK0V05	REAR OPERATION UNIT	1	(-W)
		61	VEK0V06	REAR OPERATION UNIT	1	(-D)
		62	VGU0Q97	REAR OP BUTTON	1	(-K, -S)
		62	VGU0Q98	REAR OP BUTTON	1	(-W)
		62	VGU0R05	REAR OP BUTTON	1	(-D)
		63	VXA9149	REAR PLATE UNIT	1	
		64	VYK6R50	REAR CASE UNIT	1	(-K, -S)
		64	VYK6R51	REAR CASE UNIT	1	(-W)
		64	VYK6R52	REAR CASE UNIT	1	(-D)
		65	VYQ8809	LCD UNIT	1	
		66	VYK6R68	FRONT-MOUNT UNIT	1	(-K)
		66	VYK6R69	FRONT-MOUNT UNIT	1	(-S)

Model No. : DMC-GM1K/GM1W Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		66	VYK6R70	FRONT-MOUNT UNIT	1	(-W)
		66	VYK6R71	FRONT-MOUNT UNIT	1	(-D)
		66-1	VDW2731	LENS RING	1	(-K)
		66-1	VDW2732	LENS RING	1	(-S, -W, -D)
		66-2	VYQ8807	STRAP HOLDER L	1	
		66-4	VYQ8808	STRAP HOLDER R	1	
		66-5	VGK4170	FRONT GRIP SHEET L	1	(-K, -S)
		66-5	VGK4171	FRONT GRIP SHEET L	1	(-W)
		66-5	VGK4196	FRONT GRIP SHEET L	1	(-D)
		66-6	VGK4172	FRONT GRIP SHEET R	1	(-K, -S)
		66-6	VGK4173	FRONT GRIP SHEET R	1	(-W)
		66-6	VGK4197	FRONT GRIP SHEET R	1	(-D)
		66-7	VMD6652	MOUNT	1	
		66-8	VMC2063	MOUNT SPRING	1	
		68	VGQ1R45	MAIN PCB COVER	1	
		70	VMB4771	FLASH SPRING	1	
		B1	VHD2240	SCREW	1	
		B2	VHD2325	SCREW	1	(-K)
		B2	VHD2324	SCREW	1	(-S, -W, -D)
		B3	VHD2325	SCREW	1	(-K)
		B3	VHD2324	SCREW	1	(-S, -W, -D)
		B4	VHD2333	SCREW	1	(-K, -S)
		B4	VHD2102	SCREW	1	(-W, -D)
		B5	VHD2333	SCREW	1	(-K, -S)
		B5	VHD2102	SCREW	1	(-W, -D)
		B6	VHD2333	SCREW	1	(-K, -S)
		B6	VHD2102	SCREW	1	(-W, -D)
		B7	VHD2333	SCREW	1	(-K, -S)
		B7	VHD2102	SCREW	1	(-W, -D)
		B8	VHD2333	SCREW	1	(-K, -S)
		B8	VHD2102	SCREW	1	(-W, -D)
		B9	XQN14+BJ4FJK	SCREW	1	
		B13	XQN14+BJ4FJK	SCREW	1	
		B14	XQN14+BJ4FJK	SCREW	1	
		B15	XQN14+BJ4FJK	SCREW	1	
		B16	VHD2102	SCREW	1	
		B17	VHD2102	SCREW	1	
		B18	VHD2102	SCREW	1	
		B19	VHD2102	SCREW	1	
		B20	VHD2102	SCREW	1	
		B21	VHD2124	SCREW	1	
		B22	VHD2124	SCREW	1	
		B23	VHD2190	SCREW	1	
		B24	VHD2190	SCREW	1	
		B25	VHD2331-A	SCREW	1	
		B26	VHD2331-A	SCREW	1	
		B27	VHD2331-A	SCREW	1	
		B28	VHD2520	SCREW	1	
		B29	VHD1998	SCREW	1	
		B30	VHD1998	SCREW	1	
		B31	VHD2368	SCREW	1	
		B32	XQN16+B3FJ	SCREW	1	
		B33	XQN16+B3FJ	SCREW	1	
		B34	VHD2462	SCREW	1	
		B35	VHD1754-B	SCREW	1	
		B36	VHD1754-B	SCREW	1	
		200	VXW1704	LENS UNIT	1	(GM1K, GM1W) -K
		200	VXW1705	LENS UNIT	1	(GM1K, GM1W) -S, -W, -D
		201	VYC1134	DECORATION RING	1	(GM1K, GM1W)
		203	-----	LENS MAIN UNIT	1	(GM1K, GM1W) (NOT SUPPLIED)
		206	VEK0U87	MOUNT CONTACT UNIT	1	(GM1K, GM1W)
		207	VXW1726	L MOUNT UNIT	1	(GM1K, GM1W)

Model No. : DMC-GM1K/GM1W Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		208	-----	SHADING FRAME	1	(GM1K,GM1W) (NOT SUPPLIED)
		211	VMG2117	FLOATING RUBBER	1	(GM1K,GM1W)
		212	VMG2117	FLOATING RUBBER	1	(GM1K,GM1W)
		213	VMG2117	FLOATING RUBBER	1	(GM1K,GM1W)
		214	VXW1724	REAR FRAME UNIT	1	(GM1K,GM1W) -K
		214	VXW1725	REAR FRAME UNIT	1	(GM1K,GM1W) -S, -W, -D
		220	VDW2714	P.C.B. FRAME	1	(GM1K,GM1W)
		B201	VHD2246	SCREW	1	(GM1K,GM1W)
		B202	VHD2246	SCREW	1	(GM1K,GM1W)
		B203	VHD2299	SCREW	1	(GM1K,GM1W)
		B204	VHD2299	SCREW	1	(GM1K,GM1W)
		B205	VHD2299	SCREW	1	(GM1K,GM1W)
		B206	VHD2298	SCREW	1	(GM1K,GM1W)
		B207	VHD2296	SCREW	1	(GM1K,GM1W)
		B208	VHD2296	SCREW	1	(GM1K,GM1W)
		B209	VHD2296	SCREW	1	(GM1K,GM1W)
		B210	VHD2296	SCREW	1	(GM1K,GM1W)
		B211	VHD2296	SCREW	1	(GM1K,GM1W)
		B212	VHD2296	SCREW	1	(GM1K,GM1W)
		B213	VHD2296	SCREW	1	(GM1K,GM1W)
		B214	VHD2296	SCREW	1	(GM1K,GM1W)
		B215	VHD2296	SCREW	1	(GM1K,GM1W)
		300	VXW1663	LENS UNIT	1	(GM1W) [SPC]
		301	VEJ2310	MOUNT CONTACT UNIT	1	(GM1W) [SPC]
		302	VXQ2434	L MOUNT UNIT	1	(GM1W) [SPC]
		303	-----	SHADING FRAME	1	(GM1W) (NOT SUPPLIED)
		304	VMB4295	1ST PUSH SPRING	1	(GM1W) [SPC]
		305	VMX3794	SPRING HOLDER	1	(GM1W) [SPC]
		306	VYC1124	DECORATION RING UNIT	1	(GM1W) [SPC]
		307	VDS0246	L7 LENS COVER	1	(GM1W) [SPC]
		314	VYF3554	REAR FRAME UNIT	1	(GM1W) [SPC]
		315	-----	LENS MAIN UNIT	1	(GM1W) (NOT SUPPLIED)
		B301	VHD2142	SCREW	1	(GM1W) [SPC]
		B302	VHD2142	SCREW	1	(GM1W) [SPC]
		B303	VHD2142	SCREW	1	(GM1W) [SPC]
		B304	VHD2299	SCREW	1	(GM1W) [SPC]
		B305	VHD2299	SCREW	1	(GM1W) [SPC]
		B306	VHD2299	SCREW	1	(GM1W) [SPC]
		B307	VHD1868	SCREW	1	(GM1W) [SPC]
		B308	VHD2298	SCREW	1	(GM1W) [SPC]
		B309	VHD2296	SCREW	1	(GM1W) [SPC]
		B310	VHD2296	SCREW	1	(GM1W) [SPC]
		B311	VHD2296	SCREW	1	(GM1W) [SPC]
		B312	VHD2073	SCREW	1	(GM1W) [SPC]
		B313	VHD2073	SCREW	1	(GM1W) [SPC]
		B314	XQN16+BJ45FN	SCREW	1	(GM1W) [SPC]
		B315	XQN16+BJ45FN	SCREW	1	(GM1W) [SPC]
		B316	XQN16+BJ45FN	SCREW	1	(GM1W) [SPC]
		400	VYF3562	LENS CAP	1	(GM1K)
		401	VFF1316A	CAMERA BAG	1	(GM1K)
		402	DE-A98AA/SX	BATTERY CHARGER	1	(GM1K) EG, PU, EC, EF, EB, EE, GN
		402	DE-A99BC/SX	BATTERY CHARGER	1	(GM1K) P, PC
		402	DE-A98BA/SX	BATTERY CHARGER	1	(GM1K) GC, GH, GD
		402	DE-A98CA/SX	BATTERY CHARGER	1	(GM1K) GT
		402	DE-A98DC/SX	BATTERY CHARGER	1	(GM1K) GK
		403	K1HY08YY0031	USB CABLE W/PLUG	1	(GM1K)
		405	VFC5071	SHOULDER STRAP	1	(GM1K)
		406	VFF1244	CD-ROM (INSTRUCTION BOOK)	1	(GM1K) EG, EC, EF, EB See "Notes"
		406	VFF1243	CD-ROM (INSTRUCTION BOOK)	1	(GM1K) P, PC, PU See "Notes"
		406	VFF1245	CD-ROM (INSTRUCTION BOOK)	1	(GM1K) EE, GC, GH, GN See "Notes"
		406	VFF1246	CD-ROM (INSTRUCTION BOOK)	1	(GM1K) GT, GD See "Notes"
		406	VFF1247	CD-ROM (INSTRUCTION BOOK)	1	(GM1K) GK See "Notes"

Model No. : DMC-GM1K/GM1W Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		407	VPF1542	BAG, POLYETHYLENE	1	(GM1K)
		408	-----	BATTERY	1	(GM1K)
		409	VQT5D52	BASIC O/I (GERMAN/FRENCH)	1	(GM1K)EG
		409	VQT5D53	BASIC O/I (ITALIAN/DUTCH)	1	(GM1K)EG
		409	VQT5D49	BASIC O/I (ENGLISH/SPANISH)	1	(GM1K)P
		409	VQT5D50	BASIC O/I (ENGLISH/CANADIAN FRENCH)	1	(GM1K)PC
		409	VQT5D51	BASIC O/I (SPANISH/PORTUGUESE)	1	(GM1K)PU
		409	VQT5D54	BASIC O/I (SPANISH/PORTUGUESE)	1	(GM1K)EC
		409	VQT5D55	BASIC O/I (SWEDISH/DANISH)	1	(GM1K)EC
		409	VQT5D56	BASIC O/I (FINNISH)	1	(GM1K)EC
		409	VQT5D57	BASIC O/I (FRENCH)	1	(GM1K)EF
		409	VQT5D58	BASIC O/I (ENGLISH)	1	(GM1K)EB
		409	VQT5D59	BASIC O/I (RUSSIAN/UKRAINIAN)	1	(GM1K)EE
		409	VQT5D60	BASIC O/I (ENGLISH/CHINESE (TRADITIONAL))	1	(GM1K)GC
		409	VQT5D61	BASIC O/I (ARABIC/VIETNAMESE)	1	(GM1K)GC
		409	VQT5D62	BASIC O/I (ENGLISH/CHINESE (TRADITIONAL))	1	(GM1K)GH
		409	VQT5D63	BASIC O/I (CHINESE (TRADITIONAL))	1	(GM1K)GT
		409	VQT5D64	BASIC O/I (CHINESE (SIMPLIFIED))	1	(GM1K)GK
		409	VQT5D65	BASIC O/I (ENGLISH)	1	(GM1K)GN
		409	VQT5D66	BASIC O/I (KOREAN)	1	(GM1K)GD
		410	VFF1240-C	CD-ROM (SOFT)	1	(GM1K)Except GK
		410	VFF1241-C	CD-ROM (SOFT)	1	(GM1K)GK
		411	VQL2C67-4A	OPERATING LABEL	1	(GM1K)PC
		411	VQL2C68-3A	OPERATING LABEL	1	(GM1K)GT
		412	VQL2J61	GD LABEL	1	(GM1K)GD
		414	VPN7729	PAD A	1	(GM1K)Except P, PC
		415	VPK5714	PACKING CASE	1	(GM1K)Except GK
		415	VPK5716	PACKING CASE	1	(GM1K)GK
		416	VPN7697	ACCESSORIES BOX	1	(GM1K)
		417	VPN7747	PAD B	1	(GM1K)P, PC
		418	VPN7696	TRAY	1	(GM1K)
		419	VPN7730	PAD C	1	(GM1K)
		424	VQL2Z72	COLOR LABEL	1	(GM1K)-D Except GK-D
		424	VQL2T97	COLOR LABEL	1	(GM1K)-S Except GK-S
		424	VQL2T98	COLOR LABEL	1	(GM1K)-W
		424	VQL2Z73	COLOR LABEL	1	(GM1K)GK-D
		424	VQL2V11	COLOR LABEL	1	(GM1K)GK-S
		450	K2CQ2YY00082	AC CORD W/PLUG	1	(GM1K)EG, EC, EF, EE, GC
		450	K2CA2CA00025	AC CORD W/PLUG	1	(GM1K)PU
		450	K2CT3YY00034	AC CORD W/PLUG	1	(GM1K)EB, GH
		450	K2CA2YY00129	AC CORD W/PLUG	1	(GM1K)GT
		450	K2CA2YY00130	AC CORD W/PLUG	1	(GM1K)GK
		450	K2CJ2YY00052	AC CORD W/PLUG	1	(GM1K)GN
		450	K2CR2YY00026	AC CORD W/PLUG	1	(GM1K)GD
		453	K2CT3YY00034	AC CORD W/PLUG	1	(GM1K)GC
		500	VYF3562	LENS CAP	1	(GM1W)
		501	VPF1316A	CAMERA BAG	1	(GM1W)
		502	DE-A98AA/SX	BATTERY CHARGER	1	(GM1W)
		503	K1HY08YY0031	USB CABLE W/PLUG	1	(GM1W)
		504	VFC5097	HAND GRIP UNIT	1	(GM1W)
		505	VFC5071	SHOULDER STRAP	1	(GM1W)
		506	VFF1244	CD-ROM (INSTRUCTION BOOK)	1	(GM1W) See "Notes"
		507	VPF1542	BAG, POLYETHYLENE	1	(GM1W)
		508	-----	BATTERY	1	(GM1W)
		509	VQT5D52	BASIC O/I (GERMAN/FRENCH)	1	(GM1W)EG
		509	VQT5D53	BASIC O/I (ITALIAN/DUTCH)	1	(GM1W)EG
		509	VQT5D54	BASIC O/I (SPANISH/PORTUGUESE)	1	(GM1W)EC
		509	VQT5D55	BASIC O/I (SWEDISH/DANISH)	1	(GM1W)EC
		509	VQT5D56	BASIC O/I (FINNISH)	1	(GM1W)EC
		509	VQT5D57	BASIC O/I (FRENCH)	1	(GM1W)EF

Model No. : DMC-GM1K/GM1W Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		510	VFF1240-C	CD-ROM (SOFT)	1	(GM1W)
		513	VPN7743	PAD D	1	(GM1W)
		515	VPK5723	PACKING CASE	1	(GM1W)
		516	VPN7742	ACCESSORIES BOX	1	(GM1W)
		518	VPN7696	TRAY	1	(GM1W)
		520	VPN7764	PAD E	1	(GM1W)
		530	VPF1473	LENS BAG	1	(GM1W)
		531	VPF1535	AIR CAP BAG	1	(GM1W)
		532	VPN7751	PAD F	1	(GM1W)
		550	K2CQ2YY00082	AC CORD W/PLUG	1	(GM1W)
		551	VYF3371	LENS FRONT CAP	1	(GM1W) [SPC]
		552	VFC4605	LENS REAR CAP	1	(GM1W) [SPC]