

DMC-TZ18EG-S

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
##	VEP58148A	FLASH P.C.B.	1	(RTL) E.S.D.
##	VEP50080B	TOP OPERATION P.C.B	1	(RTL) E.S.D.
##	VEP51029A	SD CARD P.C.B.	1	(RTL) E.S.D.[PAVCSG]
##	VEP50079A	GYRO P.C.B.	1	(RTL) E.S.D.[PAVCSG]
##	VEP58148A	FLASH P.C.B.	1	(RTL) E.S.D.
C8001	F1G0J1050007	C.CAPACITOR CH 6.3V 1U	1	
C8006	F1K2E4730005	C.CAPACITOR 250V 0.047U	1	
C8007	ECJ0EC1H220J	C.CAPACITOR CH 50V 22P	1	
C8009	ECJ2FB0J106M	C.CAPACITOR CH 6.3V 10U	1	
D8002	B0ECFR000003	DIODE	1	E.S.D.
△ F8001	ERBSE1R25U	FUSE 32V 1.25A	1	
△ F8002	ERBSE2R00U	FUSE 32V 2.0A	1	
IC8101	C0ZBZ0001817	IC	1	E.S.D.
P8002	K4Z204000051	CONNECTOR 4P	1	
PP8001	K1KA20A00306	CONNECTOR 20P	1	
Q8001	B1JBLP000022	TRANSISTOR	1	E.S.D.
R8001	ERJ6GEY0R00V	M.RESISTOR CH 1/8W 0	1	
R8002	ERJ3GEYJ104	M.RESISTOR CH 1/10W 100K	1	
R8003	ERJ3GEYJ680	M.RESISTOR CH 1/10W 68	1	
R8004	ERJ3GEY0R00	M.RESISTOR CH 1/10W 0	1	
R8005	ERJ6GEYJ514V	M.RESISTOR CH 1/8W 510K	1	
R8006	ERJ6GEYJ514V	M.RESISTOR CH 1/8W 510K	1	
R8013	ERJ2RHD1621	M.RESISTOR CH 1/16W 1620	1	
R8021	ERJ2GEJ513X	M.RESISTOR CH 1/16W 51K	1	
R8032	D1BD4703A119	SURFACE MOUNTING PRECISIO	1	
T8001	GSD1A0000082	TRANSFORMER	1	
T8002	G5F1A0000026	CHIP INDUCTOR	1	
##	VEP50080B	TOP OPERATION P.C.B	1	(RTL) E.S.D.
C7310	F1H0J475A010	C.CAPACITOR CH 6.3V 4.7U	1	
C7311	F1G1H1020008	C.CAPACITOR CH 50V 1000P	1	
D9901	B3ADB0000142	DIODE	1	E.S.D.
ET9901	K4AC01D00001	EARTH SPRING	1	
ET9902	K4AC01D00001	EARTH SPRING	1	
ET9903	N9ZZ00000333	EARTH SPRING	1	
FP9902	K1MN04BA0208	CONNECTOR 4P	1	
IC7310	L2ES00000022	IC	1	E.S.D.
LB9913	J0JCC0000415	FILTER	1	
PS9901	K1KB40AA0123	CONNECTOR 40P	1	
PS9903	K1KA20A00275	CONNECTOR 20P	1	
R9901	ERJ2GEJ112	M.RESISTOR CH 1/16W 1.1K	1	
R9902	ERJ2GEJ152	M.RESISTOR CH 1/16W 1.5K	1	
R9903	ERJ2GEJ182	M.RESISTOR CH 1/10W 1.8K	1	
R9904	ERJ2GEJ242	M.RESISTOR CH 1/16W 2.4K	1	
R9905	ERJ2GEJ332	M.RESISTOR CH 1/16W 3.3K	1	
R9906	ERJ2GEJ512X	M.RESISTOR CH 1/16W 5.1K	1	
R9907	ERJ2GEJ822	M.RESISTOR CH 1/10W 8.2K	1	
R9908	ERJ2GEJ163X	M.RESISTOR CH 1/16W 16K	1	
R9909	ERJ2GEJ473	M.RESISTOR CH 1/16W 47K	1	
R9910	ERJ2GEJ242	M.RESISTOR CH 1/16W 2.4K	1	
R9911	ERJ2GEJ392	M.RESISTOR CH 1/10W 3.9K	1	
R9912	ERJ2GEJ752X	M.RESISTOR CH 1/10W 7.5K	1	
R9916	ERJ2GEJ203X	M.RESISTOR CH 1/16W 22K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R9928	ERJ3GEYJ160	M.RESISTOR CH 1/10W 16	1	
R9929	ERJ3GEYJ160	M.RESISTOR CH 1/10W 16	1	
R9951	ERJ2GEJ102X	M.RESISTOR CH 1/16W 1K	1	
S9901	K0MZ26000005	SWITCH	1	
S9902	K0D112B00145	SWITCH	1	
S9903	K0F111A00583	SWITCH	1	
S9904	K0G199A00012	SWITCH	1	
##	VEP51029A	SD CARD P.C.B.	1	(RTL) E.S.D.[PAVCSG]
C6402	F1J0J226A014	C.CAPACITOR CH 6.3V 22U	1	[PAVCSG]
FP6401	K1MY15BA0235	CONNECTOR 15P	1	[PAVCSG]
P6401	K1NA09E00098	SD CARD CONNECTOR	1	[PAVCSG]
R6401	ERJ2GE0R00X	M.RESISTOR CH 1/10W 0	1	[PAVCSG]
R9913	ERJ2GEJ512X	M.RESISTOR CH 1/16W 5.1K	1	[PAVCSG]
##	VEP50079A	GYRO P.C.B.	1	(RTL) E.S.D.[PAVCSG]
C9701	F1H0J475A010	C.CAPACITOR CH 6.3V 4.7U	1	[PAVCSG]
C9702	F1G1E102A086	25V 1000P	1	[PAVCSG]
FP9701	K1MY04BA0370	CONNECTOR 4P	1	[PAVCSG]
IC9701	L2ES00000021	IC	1	[PAVCSG]

DMC-TZ18EG-S

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VEP56125A	MAIN P.C.B.	1	(RTL) E.S.D.
4	L0AA01A00032	SPEAKER	1	
5	L0CBAA000016	MICROPHONE UNITS	1	
6	VGL1268	AF PANEL LIGHT	1	
7	VGQ0S26	FRASH SPACER	1	
8	VGQ0U66	TOP INSULATION TAPE	1	
9	VEP50080B	TOP OPERATION P.C.B	1	(RTL) E.S.D.
10	VYK4L76	TOP CASE ASS'Y	1	EG,EP,EB,EF,EE,GC,GN,PR
10	VYK4L77	TOP CASE ASS'Y	1	P,PC,PU,GH,GK
11	VMP9895	FRAME	1	[PAVCSG]
12	VKF4812	JACK DOOR	1	[PAVCSG]
13	ML-421S/DN	BUTTON BATTERY	1	(B9901) [ENERGY]
14	VMS8146	JACK DOOR SHAFT	1	[PAVCSG]
15	VMS7863	BATTERY DOOR SHAFT	1	[PAVCSG]
16	VYK4T90	BATTERY DOOR ASS'Y	1	(-S) [PAVCSG]
16	VYK4T91	BATTERY DOOR ASS'Y	1	(-K) [PAVCSG]
17	VEK0R27	FLASH U	1	
18	VEP58148A	FLASH P.C.B.	1	(RTL) E.S.D.
21	VEP50079A	GYRO P.C.B.	1	(RTL) E.S.D.[PAVCSG]
22	VYK4T52	FRONT CASE ASS'Y(1)	1	EG-S,EP-S,EB-S,EE-S,GC-S, GN-S,PC-S,PU-S,GH-S,GK-S [PAVCSG]
22	VYK4T53	FRONT CASE ASS'Y(1)	1	EG-K,EP-K,EB-K,EF-K,EE-K, GC-K,GN-K,PR-K,PC-K, PU-K,GH-K,GK-K [PAVCSG]
22	VYK4T54	FRONT CASE ASS'Y(1)	1	P-S [PAVCSG]
22	VYK4T55	FRONT CASE ASS'Y(1)	1	P-K [PAVCSG]
22-1	VGQ0S21	LENS ORNAMENT	1	[PAVCSG]
23	VEP51029A	SD CARD P.C.B.	1	(RTL) E.S.D.[PAVCSG]
24	VYK4U15	LCD ASS'Y	1	
24-1	VYK5C82	LCD PANEL U	1	
24-2	VGQ0W39	FPC FIX TAPE	1	
26	VWJ2240	SD MAIN JOINT FPC	1	[PAVCSG]
27	VMP0A02	FRAME PLATE 1	1	
29	VMB4507	BATTERY LOCK SPRING	1	[PAVCSG]
30	VGQ0L97	BATTERY LOCK KNOB	1	[PAVCSG]
32	VMP9912	EARTH PLATE L	1	
33	VGQ0J81	TROPID	1	[PAVCSG]
34	VMB4462	EARTH SPRING	1	(ET8001)
35	VMB4143	BATTERY DOOR SPRING	1	[PAVCSG]
36	VMB4305	BATTERY OUT SPRING	1	[PAVCSG]
37	VMP9896	BATTERY CASE	1	[PAVCSG]
38	VWJ2241	GYRO FPC	1	[PAVCSG]
39	F2A2F9500007	CAPACITOR	1	(C8003)
41	VGQ0P04	FPC SHEET	1	[PAVCSG]
42	VGQ0P04	FPC SHEET	1	[PAVCSG]
45	VGQ0S27	CONDENSER SPACER	1	
46	VGK3739	SIDE ORNAMENT L	1	
47	VGK3740	SIDE ORNAMENT R	1	
48	VYK4T70	REAR CASE ASS'Y (1)	1	(-S) [PAVCSG]
48	VYK4T71	REAR CASE ASS'Y (1)	1	(-K) [PAVCSG]
48-1	VGU0H72	CURSOR BUTTON	1	[PAVCSG]
48-2	VGU0H73	MENU BUTTON	1	[PAVCSG]
48-3	VGU0H74	SLIDE KNOB	1	[PAVCSG]
48-4	VGQ0X09	PROTECTION SHEET	1	
56	VGQ0S28	PCB SPACER	1	[PAVCSG]
61	VGQ0W96	CONNECTOR SHEET	1	
63	VGQ0X10	ORNAMENT TAPE	1	
64	VGQ0X13	MIC FPC SHEET	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
201	VEK0R68	CCD U	1	
202	VXP3523	1ST LENS FRAME UNIT	1	
203	VXP3525	1ST DIRECT FRAME	1	
204	VDW2175	BOTH SIDE CAM FRAME	1	
205	VXP3526	2ND LENS FRAME UNIT	1	
206	VXP3527	3RD LENS FRAME UNIT	1	
207	VDW2179	2ND/3RD DIRECT FRAME	1	
210	VXQ1999	FIX CAM FRAME UNIT	1	
211	VDW2183	ROTARY FRAME	1	
212	VXQ2081	MASTER FRANGE UNIT	1	[PAVCSG]
212-1	VXP3530	4TH LENS FRAME UNIT	1	[PAVCSG]
212-2	VMB4251	FOCUS SPRING	1	[PAVCSG]
212-3	VXP3531	5TH LENS FRAME UNIT	1	[PAVCSG]
212-4	L6HAYYYC0036	STEPPING MOTORS	1	[PAVCSG]
212-5	VMB4448	5TH SPRING	1	[PAVCSG]
212-6	VDW2224	FOCUS COVER	1	[PAVCSG]
213	L6DAYYYC0002	ZOOM MOTOR UNIT	1	[PAVCSG]
214	VEK0R13	LENS FPC	1	[PAVCSG]
214-1	B3NBA0000018	PHOTO SENSOR	1	[PAVCSG]
214-2	B3NBA0000018	PHOTO SENSOR	1	[PAVCSG]
214-3	K1MY10BA0454	CONNECTOR(10P)	1	[PAVCSG]
214-4	K1MY24BA0454	CONNECTOR(24P)	1	[PAVCSG]
216	VXW1201	LENS UNIT (W/O CCD)	1	
B1	VHD2071	LENS SCREW	1	
B2	VHD2071	LENS SCREW	1	
B3	VHD2071	LENS SCREW	1	
B4	VHD2081	SCREW	1	
B5	VHD2081	SCREW	1	
B6	VHD1909	SCREW	1	
B7	VHD1909	SCREW	1	
B8	VHD1909	SCREW	1	
B9	XQN14+BJ35FN	SCREW	1	
B10	XQN14+BJ35FN	SCREW	1	
B13	VHD1924-A	SCREW	1	[PAVCSG]
B14	VHD1924-A	SCREW	1	[PAVCSG]
B15	VHD1924-A	SCREW	1	[PAVCSG]
B16	VHD1924-A	SCREW	1	[PAVCSG]
B17	VHD2207	SCREW	1	
B18	VHD2207	SCREW	1	
B19	VHD2207	SCREW	1	
B20	VHD2207	SCREW	1	
B21	VHD2207	SCREW	1	
B26	VHD2207	SCREW	1	
B27	VHD2207	SCREW	1	
B28	VHD2081	SCREW	1	[PAVCSG]
B201	VHD1871	SCREW	1	
B202	VHD1871	SCREW	1	
B203	VHD1871	SCREW	1	
B204	VHD2296	SCREW	1	
B205	VHD2296	SCREW	1	
B206	VHD2296	SCREW	1	
B207	VHD2109	SCREW	1	[PAVCSG]
B208	VHD2296	SCREW	1	[PAVCSG]
B209	VHD2296	SCREW	1	[PAVCSG]
B210	VHD2296	SCREW	1	[PAVCSG]
B211	VHD2296	SCREW	1	
B212	VHD2296	SCREW	1	[PAVCSG]


DMC-TZ18EG-S

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
301	VPF1137	CAMERA BAG	1	EG,EP,EB,EF,EE,GC,GN,PR, PU,GH,GK
302	VPK4951	PACKING CASE	1	EG-S,EP-S,EB-S,EE-S,GC-S, GN-S
302	VPK4955	PACKING CASE	1	EG-K,EP-K,EB-K,EF-K,EE-K, GC-K,GN-K,PR-K
302	VPK4952	PACKING CASE	1	PU-S,GH-S
302	VPK4956	PACKING CASE	1	PU-K,GH-K
302	VPK4953	PACKING CASE	1	GK-S
302	VPK4957	PACKING CASE	1	GK-K
△ 303	K2CA2Y00070	AC CORD	1	GK
△ 303	K2CQ29A00002	AC CORD	1	EG,EP,EF,EE,GC
△ 303	K2CT39A00002	AC CORD	1	EB,GC,GH
△ 303	K2CJ29A00002	AC CORD	1	GN
△ 303	K2CJ29A00003	AC CORD	1	PR-K
△ 304	----	BATTERY PACK	1	(NOT SUPPLIED)
305	VFF0772-S	CD-ROM (SOFT/INSTRUCTION BOOK)	1	EG,EP,EB,EF See "Notes"
305	VFF0773-S	CD-ROM (SOFT/INSTRUCTION BOOK)	1	EE See "Notes"
305	VFF0774-S	CD-ROM (SOFT/INSTRUCTION BOOK)	1	GC,GN,GH See "Notes"
305	VFF0775-S	CD-ROM (SOFT/INSTRUCTION BOOK)	1	GK See "Notes"
305	VFF0771-S	CD-ROM (SOFT/INSTRUCTION BOOK)	1	PR,PU See "Notes"
△ 306	DE-A66AA	BATTERY CHARGER	1	EG,EP,EB,EF,GN
△ 306	DE-A66BB	BATTERY CHARGER	1	EE,GC,GH,GK
△ 306	DE-A66DA	BATTERY CHARGER	1	PR
306	DE-A65BA	BATTERY CHARGER	1	PU
△ 307	VQT3H29	BASIC O/I	1	EG (GERMAN/FRENCH)
△ 307	VQT3H30	BASIC O/I	1	EG (ITALIAN/DUTCH)
△ 307	VQT3H31	BASIC O/I	1	EG (SPANISH/PORTUGUESE)
△ 307	VQT3H32	BASIC O/I	1	EG (TURKISH)
△ 307	VQT3H33	BASIC O/I	1	EP (SWEDISH/DANISH)
△ 307	VQT3H34	BASIC O/I	1	EP (POLISH/CZECH)
△ 307	VQT3H35	BASIC O/I	1	EP (HUNGARIAN/FINNISH)
△ 307	VQT3H37	BASIC O/I	1	EB (ENGLISH)
△ 307	VQT3H36	BASIC O/I	1	EF (FRENCH)
△ 307	VQT3H38	BASIC O/I	1	EE (RUSSIAN/UKRAINIAN)
△ 307	VQT3H39	BASIC O/I	1	GC,GH (ENGLISH/ CHINESE(TRADITIONAL))
△ 307	VQT3H40	BASIC O/I	1	GC (ARABIC/PERSIAN)
△ 307	VQT3M14	BASIC O/I	1	GC (VIETNAMESE)
△ 307	VQT3H42	BASIC O/I	1	GN (ENGLISH)
△ 307	VQT3H28	BASIC O/I	1	PR (SPANISH)
△ 307	VQT3H27	BASIC O/I	1	PU (SPANISH/PORTUGUESE)
△ 307	VQT3H41	BASIC O/I	1	GK (CHINESE(SIMPLIFIED))
308	K1HY08YY0017	USB CABLE	1	EG,EP,EB,EF,EE,GC,GN,PR, PU,GH,GK
309	K1HY08YY0018	AV CABLE	1	EG,EP,EB,EF,EE,GC,GN,PR, PU,GH,GK
310	VFC4297	HAND STRAP	1	EG,EP,EB,EF,EE,GC,GN,PR, PU,GH,GK
312	VPN7189	CUSHION	1	EG,EP,EB,EF,EE,GC,GN,PR, PU,GH,GK
313	VPF1230	POLYETHYLENE COVER	1	EG,EP,EB,EF,EE,GC,GN,PR, PU,GH,GK

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
315	VQC8057	O/I SOFTWARE	1	EG (GERMAN/ITALIAN/FRENCH/ DUTCH/SPANISH/ PORTUGUESE/TURKISH)
315	VQC8058	O/I SOFTWARE	1	EP (FINNISH/SWEDISH/DANISH/ POLISH/CZECH/HUNGARIAN)
315	VQC8060	O/I SOFTWARE	1	EB,GN (ENGLISH)
315	VQC8059	O/I SOFTWARE	1	EF (FRENCH)
315	VQC8061	O/I SOFTWARE	1	EE (RUSSIAN/UKRAINIAN)
315	VQC8062	O/I SOFTWARE	1	GC,GH (ENGLISH/ CHINESE(TRADITIONAL)/ ARABIC/PERSIAN)
315	VQC8056	O/I SOFTWARE	1	PR,PU (SPANISH/PORTUGUESE)
315	VQC8064	O/I SOFTWARE	1	GK (CHINESE(SIMPLIFIED))
----- PACKING SECTION P, PC -----				
401	VPF1137	CAMERA BAG	1	P,PC
402	VPK4950	PACKING CASE	1	P-S,PC-S
402	VPK4954	PACKING CASE	1	P-K,PC-K
△ 404	----	BATTERY PACK	1	(NOT SUPPLIED)
405	VFF0771-S	CD-ROM (SOFT/INSTRUCTION BOOK)	1	P,PC See "Notes"
△ 406	DE-A65BA	BATTERY CHARGER	1	P,PC
△ 407	VQT3H25	BASIC O/I	1	P (ENGLISH/SPANISH)
△ 407	VQT3H26	BASIC O/I	1	PC (ENGLISH/CANADIAN FRENCH)
408	K1HY08YY0017	USB CABLE	1	P,PC
409	K1HY08YY0018	AV CABLE	1	P,PC
410	VFC4297	HAND STRAP	1	P,PC
412	VPN7189	CUSHION	1	P,PC
413	VPF1230	POLYETHYLENE COVER	1	P,PC
414	VQL2C67	OPERATING LABEL	1	PC
415	VQC8055	O/I SOFTWARE	1	P,PC (ENGLISH/CANADIAN FRENCH)

S7.2. Packing Parts and Accessories Section (1)

(except for P/PC)



S7.3. Packing Parts and Accessories Section (2)

(Only P,PC)

