

SEC 5. EXPLODED VIEWS


- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be allowed for these items.

The components identified by shading and mark  are critical for safety. Replace only with part number specified.

The components identified by mark  contain confidential information. Strictly follow the instructions whenever the components are repaired and/or replaced.


5-1. KDL-32EX40B/43B

5-1-1. CHASSIS-1



REF. No.		PART No.	D
1	⚠	1-837-486-11	PC
	⚠	1-837-455-11	PC
2		4-167-326-01	BL
3		4-166-124-11	CO
4		4-166-777-11	CO
5		1-487-803-11	SV
6		4-158-349-01	NI
7		X-2546-541-2	CO
8		X-2546-980-1	BA
9		X-2548-084-1	RI
10		3-106-546-51	CO

5-1. KDL-32EX40B/43B 5-1-2. CHASSIS-2




REF. No.	PART No.	DI
11	X-2548-085-1	BI
12	A-1753-636-A	HI
13	1-811-059-11	LO
14	A-1772-836-A	BA
	A-1772-837-A	BA
15	8-597-719-00	UI
	8-597-733-00	UI
16	4-166-268-02	BI
17	1-857-634-11	IN
18	A-1769-951-B	BI
	A-1769-952-B	BI
19	A-1743-521-A	HI
20	1-474-209-11	SI
21	1-858-364-22	LO
22	X-2547-479-1	BI
23	X-2547-477-1	BI
24	4-166-118-11	SI
25	1-857-636-11	TO

5-1. KDL-32EX40B/43B


5-1-3. SCREWS

	PART No.	DESCRIPTION
■	2-580-640-01	SCREW, +BVTP 4X16 TYPE2 IT-3
□	2-580-595-01	SCREW, +PSW M3X12
▼	7-685-648-79	SCREW +BVTP 3X12 TYPE2 IT-3
▽	2-580-608-01	SCREW, +PSW M5X16
●	2-580-592-01	SCREW, +PSW M3X8
○	4-159-298-01	SCREW, +PSW M4X10




5-2. KDL-40EX40B/43B

5-2-1. CHASSIS-1



REF. No.		PART No.	DI
1	⚠	1-837-486-11	PO
	⚠	1-837-455-11	PO
2		4-167-326-01	BL
3		4-166-123-11	CO
4		4-166-777-11	CO
5		1-487-803-11	SV
6		4-158-350-01	NI
7		X-2546-541-2	CO
8		X-2541-846-1	BA
9		X-2548-073-1	RI
10		3-106-546-51	CO

5-2. KDL-40EX40B/43B 5-2-2. CHASSIS-2







REF. No.	PART No.	DI
11	X-2548-083-1	BE
12	A-1753-636-A	HI
13	1-811-060-13	LC
14	A-1772-836-A	BA
	A-1772-837-A	BA
15	8-597-719-00	UI
	8-597-733-00	UI
16	4-166-268-02	BI
17	1-857-640-11	IN
18	A-1769-951-B	BI
	A-1769-952-B	BI
19	A-1743-521-A	HI
20	1-474-210-11	ST
21	1-858-364-22	LC
22	X-2547-483-1	BI
23	X-2547-481-1	BI
24	4-166-118-01	ST
25	1-857-639-11	TO

5-2. KDL-40EX40B/43B

5-2-3. SCREWS

	PART No.	DESCRIPTION
■	2-580-640-01	SCREW, +BVTP 4X16 TYPE2 IT-3
▼	7-685-648-79	SCREW +BVTP 3X12 TYPE2 IT-3
▽	2-580-608-01	SCREW, +PSW M5X16
●	2-580-592-01	SCREW, +PSW M3X8
○	4-159-298-01	SCREW, +PSW M4X10



5-3. OTHER PARTS

5-3-1. ACCESSORIES and CONNECTORS

32 INCHES

1-837-707-11	LEAD WIRE WITH CONNECTOR(LVDS) (CN2600-TCON)
1-837-802-11	CORD WITH CONNECTOR(HDMI CABLE) (CN2262-CN701)
1-837-820-11	LEAD WIRE WITH CONNECTOR(ETHER) (CN005-CN1201)
1-910-100-64	HARNESS ASSY (CN2602,CN4300-CN002,SW,SP,CN008)
1-910-100-65	CONNECTOR ASSY 15P (CN6201-CN3800,CN2561)
1-910-100-66	CONNECTOR ASSY 14P (CN6202-INV)
1-910-100-67	CONNECTOR ASSY 4P (CN6203-CN002)
1-910-100-68	CONNECTOR ASSY 6P (CN2403-CN009)
1-910-100-69	HARNESS ASSY (BD) (CN003,CN004-CN601,CN1503)
1-910-100-70	CONNECTOR ASSY 12P (CN001-CN303)
1-910-100-71	FFC CONNECTOR ASSY 5P (CN006-CN1508)

40 INCHES

1-837-708-11	FLEXIBLE FLAT CABLE (CN2600-TCON)
1-837-804-11	CORD WITH CONNECTOR(HDMI CABLE) (CN2262-CN701)
1-837-820-11	LEAD WIRE WITH CONNECTOR(ETHER) (CN005-CN1201)

1-910-100-69	HARNESS ASSY (BD) (CN003,CN004-CN601,CN1503)
1-910-100-70	CONNECTOR ASSY 12P (CN001-CN303)
1-910-100-71	FFC CONNECTOR ASSY 5P (CN006-CN1508)
1-910-100-72	HARNESS ASSY (CN2602,CN4300-CN002,SW,SP,CN008)
1-910-100-73	CONNECTOR ASSY 15P (CN6401-CN3800,CN2561)
1-910-100-74	CONNECTOR ASSY 14P (CN6202-INV)
1-910-100-75	CONNECTOR ASSY 4P (CN6203-CN002)
1-910-100-76	CONNECTOR ASSY 6P (CN2403-CN009)

5-3-2. INSTRUCTION MANUALS

*4-180-167-21	INSTRUCTION MANUAL	(40B)
*4-180-167-31	INSTRUCTION MANUAL	(40B)
*4-180-167-41	INSTRUCTION MANUAL	(40B)
*4-180-168-11	INSTRUCTION MANUAL	(43B)

5-3-3. REMOTE COMMANDER

1-487-766-11	REMOTE COMMANDER (RM-ED029)
--------------	-----------------------------

5-3-4. MISCELLANEOUS

1-822-482-11	HDMI CONNECTOR (REAR)
1-822-484-11	HDMI CONNECTOR (SIDE)
1-822-525-21	OPTICAL OUT CONNECTOR
1-821-827-21	D SUB CONNECTOR
1-821-868-11	ETHERNET CONNECTOR(8P)
1-821-834-12	USB CONNECTOR
1-822-579-31	CARD CONNECTOR (PCMCIA CARD)
1-822-580-41	CONNECTOR DUAL SCART
1-822-581-13	MULTIPLE PHONO JACK 4P
1-842-010-11	JACK
1-822-524-21	PHONO JACK 2P
1-842-096-11	PHONO JACK 5P

END

9-888-318-02

KDL-32/40EX40B Series(AEP/UK)

**Sony Corporation
Sony UK
Service Promotions Dept.**