


| Ref. No.                                                    | Part No.      | ★ | Description                        | Code | Ref. No. | Part No.       | ★ | Description                          | Code |
|-------------------------------------------------------------|---------------|---|------------------------------------|------|----------|----------------|---|--------------------------------------|------|
| <b>CABINET AND MECHANICAL PARTS<br/>(LC-26P50E/K/F/I/R)</b> |               |   |                                    |      | 5-6-2-3  | PSPAZA675WJZZ  | J | Spacer, x3                           | AB   |
|                                                             |               |   |                                    |      | 5-6-2-4  | PSPAZA676WJZZ  | J | Spacer, x2                           | AB   |
|                                                             |               |   |                                    |      | 5-6-2-5  | PSPAZA703WJZZ  | J | Spacer, x2 (Long)                    |      |
|                                                             |               |   |                                    |      | 5-6-2-6  | PSPAZA704WJZZ  | J | Spacer, x2 (Short)                   |      |
| 1                                                           | CCABAA936WJ01 | S | Front Cabinet Ass'y                |      | 5-6-3    | Not Available  | — | Lamp Ass'y                           | —    |
| 1-1                                                         | Not Available | — | Front Cabinet                      | —    | 5-6-3-1  | KLMP-A073WJZZ  | J | Lamp, x8                             |      |
| 1-2                                                         | GCOVAB240WJSA | S | R/C, LED Decoration Cover          |      | 5-6-3-2  | QCNW-D683WJQZ  | J | Connector, x7                        |      |
| 1-3                                                         | HBDGBA015WJSA | S | Badge, "SHARP"                     | AH   | 5-6-3-3  | QCNW-D686WJQZ  | J | Connector                            |      |
| 1-4                                                         | PSPAHA323WJZZ | S | Mask Spacer, x2                    | AD   |          |                |   |                                      |      |
| 1-5                                                         | PSPAHA324WJZZ | S | Mask Spacer, x2                    | AC   | 5-6-4    | LHLDZA592WJKZ  | J | Lamp Holder, x2                      |      |
| 1-6                                                         | TLABZB033WJZZ | S | POP Label                          |      | 5-6-5    | PCOVUA064WJZZ  | J | Diffusion Panel                      | AY   |
| 2                                                           | CCABBA577WJ01 | S | Rear Cabinet Ass'y                 |      | 5-6-7    | PSHEPA353WJZZ  | J | Diffusion Sheet, x2                  |      |
| 2-1                                                         | Not Available | — | Rear Cabinet                       | —    | 5-6-8    | XBPS730P06WS0  | J | Screw, x4 (for Lamp Holder)          | AA   |
| 2-2                                                         | GCOVAB232WJKA | S | Terminal Cover                     |      | 5-6-9    | XBPSN30P14000  | J | Screw, x2                            |      |
| 2-3                                                         | LHLDWA055WJKZ | S | Wire Holder for AC-cord            | AC   | 5-7      | LX-BZA051WJFN  | J | Screw, x4                            | AB   |
| 2-4                                                         | PSPAHA413WJZZ | S | Spacer                             | AB   | 5-8      | LX-BZA101WJFN  | J | Screw, x8<br>(for Panel Angle Ass'y) | AB   |
| 3                                                           | CCOVAB224WJ01 | S | Top Cover Ass'y                    |      | 5-9      | LX-BZA114WJFN  | J | Screw, x4 (for Panel)                |      |
| 3-1                                                         | Not Available | — | Top Cover                          | —    | 5-10     | QEARZA089WJFW  | J | Earth Spring, x2                     |      |
| 3-2                                                         | JBTN-A459WJKA | S | Power Button                       |      | 5-11     | TLABN2229TPZZ  | J | Code Label                           |      |
| 3-3                                                         | JBTN-A460WJKA | S | Operation Button                   |      | 5-12     | XBPS730P06WS0  | J | Screw, x2                            | AA   |
| 3-4                                                         | MSPRCA049WJFW | S | Power Button Spring                | AC   | 5-13     | XBPSN30P14000  | J | Screw, x4                            |      |
| 4                                                           | CDAI-A209WEV0 | S | Stand Ass'y                        |      | 5-14     | XEBS830P12000  | J | Screw, x10                           |      |
| 4-1                                                         | CANGTA217WJSA | S | Stand Bracket Ass'y                |      | 5-15     | XEPS930P10000  | J | Screw, x2 (for Panel Holder)         |      |
| 4-1-1                                                       | Not Available | — | Stand Bracket                      | —    | 6        | DUNTKD186DE01  | J | MAIN Unit                            |      |
| 4-1-2                                                       | GDAI-A210WJSA | S | Stand Support                      |      | 7        | DUNTKD187WE01  | — | AV Unit(iLC-26P50E)                  | —    |
| 4-2                                                         | CDAI-A209WJKA | S | Stand Base Ass'y                   |      | 7        | DUNTKD187WE02  | — | AV Unit(LC-26P50K)                   | —    |
| 4-2-1                                                       | Not Available | — | Stand Base                         | —    | 7        | DUNTKD187WE03  | — | AV Unit(LC-26P50F)                   | —    |
| 4-2-2                                                       | LANGKA502WJSA | S | Base Bracket                       |      | 7        | DUNTKD187WE04  | — | AV Unit(LC-26P50I)                   | —    |
| 4-2-3                                                       | PSPAZA476WJZZ | S | Leg-Cushion-B, x4                  | AC   | 7        | DUNTKD187WE05  | — | AV Unit(LC-26P50R)                   | —    |
| 4-2-4                                                       | PSPAZA477WJZZ | S | Leg-Cushion-C, x4                  | AD   | 8        | DUNTKD188WE01  | — | KEY Unit(LC-26P50E)                  | —    |
| 4-3                                                         | XCBS950P25000 | S | Screw, x3 (for Stand)              | AC   | 8        | DUNTKD188WE02  | — | KEY Unit(LC-26P50K)                  | —    |
| 5                                                           | Not Available | — | 26 LCD Panel Unit Ass'y            | —    | 8        | DUNTKD188WE03  | — | KEY Unit(LC-26P50F)                  | —    |
| 5-1                                                         | RLCDA049WJZZ  | J | 26 LCD Panel Unit                  |      | 8        | DUNTKD188WE04  | — | KEY Unit(LC-26P50I)                  | —    |
| 5-2                                                         | CANGTA209WJ01 | J | Panel Fixing Angle Ass'y (Top)     |      | 8        | DUNTKD188WE05  | — | KEY Unit(LC-26P50R)                  | —    |
| 5-2-1                                                       | Not Available | — | Panel Fixing Angle (Top)           | —    | 9        | DUNTKD189WE01  | — | R/C, LED Unit(LC-26P50E)             | —    |
| 5-2-2                                                       | PSPAZA687WJZZ | J | Spacer, x2                         |      | 9        | DUNTKD189WE02  | — | R/C, LED Unit(LC-26P50K)             | —    |
| 5-2-3                                                       | PSPAZA697WJZZ | J | Spacer, x2 (Short)                 | AB   | 9        | DUNTKD189WE03  | — | R/C, LED Unit(LC-26P50F)             | —    |
| 5-2-4                                                       | PSPAZA705WJZZ | J | Spacer, x1 (Long)                  |      | 9        | DUNTKD189WE04  | — | R/C, LED Unit(LC-26P50I)             | —    |
| 5-3                                                         | CANGTA210WJ01 | J | Panel Fixing Angle Ass'y (Bottom)  |      | 9        | DUNTKD189WE05  | — | R/C, LED Unit(LC-26P50R)             | —    |
| 5-3-1                                                       | Not Available | — | Panel Fixing Angle (Bottom)        | —    | 10       | RUNTKA151WJZZ  | — | INVERTER Unit                        | —    |
| 5-3-2                                                       | PSPAZA697WJZZ | J | Spacer, x2 (Short)                 | AB   | 11       | RDENCA122WJZZ  | — | POWER Unit                           | —    |
| 5-3-3                                                       | PSPAZA705WJZZ | J | Spacer, x1 (Long)                  |      | 12       | GCOVAB243WJKA  | S | ID Cover                             |      |
| 5-4                                                         | CANGTA211WJ01 | J | Panel Fixing Angle Ass'y, x2 (L-R) |      | 13       | GCOVAB245WJKA  | S | Hinge Cover                          |      |
| 5-4-1                                                       | Not Available | — | Panel Fixing Angle, x2 (L-R)       | —    | 14       | HiNDPB299WJSA  | S | Model Label (LC-26P50E/K/F)          |      |
| 5-4-2                                                       | PSPAZA706WJZZ | J | Spacer (Short), x2                 |      | 14       | HiNDPB300WJSA  | S | Model Label (LC-26P50I)              |      |
| 5-5                                                         | CHLDZA558WJ01 | J | Glass Fixing Angle Ass'y, x2       | AF   | 14       | HiNDPB436WJSA  | S | Model Label (LC-26P50R)              |      |
| 5-5-1                                                       | Not Available | — | Glass Fixing Angle, x2             | —    | 15       | LANGTA203WJFW  | S | Center Angle                         |      |
| 5-5-2                                                       | PSPAZA674WJZZ | J | Spacer, x2                         | AB   | 16       | LANGTA204WJFW  | S | Center Guide Angle                   |      |
| 5-6                                                         | CLAMPA073UJ01 | J | Back Light Ass'y                   |      | 17       | LCHSMA201WJKA  | S | Chassis Frame                        |      |
| 5-6-1                                                       | CCHSMA210WJ01 | J | Back Light Chassis Ass'y           |      | 18       | LHLDW1009CEZZ  | S | Wire Holder (OMEGA Lock)             | AA   |
| 5-6-1-1                                                     | Not Available | — | Back Light Chassis                 | —    | 19       | LHLDW1046CEZZ  | S | Wire Holder (OMEGA Lock)             | AA   |
| 5-6-1-2                                                     | LANGKA469WJFW | J | Bracket (Top-R)                    |      | 20       | LHLDWA023WJKZ  | S | Wire Holder, x2                      | AC   |
| 5-6-1-3                                                     | LANGKA470WJFW | J | Bracket (Top-L)                    |      | 21       | LHLDWA048WJKZ  | S | Wire Holder (for SP Wire)            | AB   |
| 5-6-1-4                                                     | LANGKA503WJFW | J | Bracket (Center)                   |      | 22       | PRDARA263WJFW  | S | Heat Sink                            |      |
| 5-6-1-5                                                     | LANGKA504WJFW | J | Bracket (Bottom-R)                 |      | 23       | PSLDMA708WJFW  | S | Main Shield (Top)                    |      |
| 5-6-1-6                                                     | LANGKA505WJFW | J | Bracket (Bottom-L)                 |      | 24       | PSLDMA709WJFW  | S | Main Shield (Bottom)                 |      |
| 5-6-1-7                                                     | LHLDZA591WJKZ | J | Lamp Clip, x8                      |      | 25       | PSLDMA712WJFW  | S | Inverter Shield                      |      |
| 5-6-1-8                                                     | PGUMMA010WJKA | J | Lamp Rubber, x16                   |      | 26       | PSLDMA769WJFW  | S | Tuner Shield                         |      |
| 5-6-1-9                                                     | PMIR-A076WJZZ | J | Mirror Sheet                       |      | 27       | PSPAGA243WJZZ  | S | Inverter Cushion, x2                 |      |
| 5-6-1-10                                                    | TCAUZA031WJZZ | J | Caution Label                      | AB   | 28       | PSPAZA844WJKZ  | S | Cooling Sheet for IC3300             |      |
| 5-6-1-11                                                    | XBPS730P06WS0 | J | Screw, x6                          | AA   | 29       | PSPAZA845WJKZ  | S | Cooling Sheet for IC4101             |      |
| 5-6-2                                                       | CHLDZA578WJ01 | J | Panel Holder Ass'y                 |      | 30       | PSPAZA846WJKZ  | S | Cooling Sheet for IC4503             |      |
| 5-6-2-1                                                     | Not Available | — | Panel Holder                       | —    | 31       | PSPAZA848WJKZ  | S | Cooling Sheet for IC1203             |      |
| 5-6-2-2                                                     | PSPAZA673WJZZ | J | Spacer, x2                         |      | 32       | QCNCMA201WJZZ  | S | Connecting Cord, MAIN-AV (B to B)    | AH   |
|                                                             |               |   |                                    |      | 33       | QCNW-D707WJJPZ | S | Connecting Cord, POW-INV (PD)        |      |
|                                                             |               |   |                                    |      | 34       | QCNW-D708WJJPZ | S | Connecting Cord, POW-INV (PF)        |      |
|                                                             |               |   |                                    |      | 35       | QCNW-D839WJQZ  | S | Connecting Cord, AV-KEY              |      |
|                                                             |               |   |                                    |      | 36       | QCNW-D840WJQZ  | S | Connecting Cord, AV-R/C,LED          |      |
|                                                             |               |   |                                    |      | 37       | QCNW-D841WJQZ  | S | Connecting Cord, AV-SP (SP)          |      |
|                                                             |               |   |                                    |      | 38       | QCNW-D842WJQZ  | S | Connecting Cord, AV-POWER            |      |

| Ref. No.                                                                | Part No.      | ★ | Description                          | Code |
|-------------------------------------------------------------------------|---------------|---|--------------------------------------|------|
| <b>CABINET AND MECHANICAL PARTS<br/>(LC-26P50E/K/F/I/R) (Continued)</b> |               |   |                                      |      |
| 39                                                                      | QCNW-D843WJQZ | S | Connecting Cord,<br>MAIN-POWER (PB)  |      |
| 40                                                                      | QCNW-D844WJQZ | S | Connecting Cord,<br>MAIN-POWER (PC)  |      |
| 41                                                                      | QCNW-D845WJQZ | S | Connecting Cord,<br>INV_GND-GND      |      |
| 42                                                                      | QEARPA187WJZZ | S | Earth Plate, x4                      |      |
| 43                                                                      | QPWBMD143WJPZ | S | Connecting Cord, x2<br>(INV_GND-GND) | AM   |
| 44                                                                      | RSP-ZA120WJZZ | S | Speaker Box (L)                      |      |
| 45                                                                      | RSP-ZA121WJZZ | S | Speaker Box (R)                      |      |
| 46                                                                      | XBBS930P06000 | S | Screw, x3<br>(for AC Angle, HDMI)    | AA   |
| 47                                                                      | XBBS940P10000 | S | Screw, x6 (for Hinge Cover)          | AB   |
| 48                                                                      | XBBSN50P12JS0 | S | Screw, x4 (for Stand)                | AF   |
| 49                                                                      | XBPS730P04WS0 | S | Screw, x2<br>(for INVERTER_S Frame)  |      |
| 50                                                                      | XBPS730P06WS0 | S | Screw, x10<br>(for INVERTER, POWER)  | AA   |
| 51                                                                      | XBPS730P08WS0 | S | Screw, x24 (for Chassis)             |      |
| 52                                                                      | XEBS930P08000 | S | Screw, x9 (for Terminal)             | AA   |
| 53                                                                      | XEBS940P16000 | S | Screw, x13<br>(for Rear Cabinet)     | AB   |
| 54                                                                      | XEBSN40P10000 | S | Screw, x6 (for VESA)                 | AB   |


# CABINET AND MECHANICAL PARTS (LC-26P50E)



| Ref. No.                                                    | Part No.       | ★ | Description                           | Code | Ref. No. | Part No.      | ★ | Description                   | Code |
|-------------------------------------------------------------|----------------|---|---------------------------------------|------|----------|---------------|---|-------------------------------|------|
| <b>CABINET AND MECHANICAL PARTS<br/>(LC-32P50E/K/F/I/R)</b> |                |   |                                       |      | 5-7-1-4  | LANGKA500WJFW | J | Top Angle L                   |      |
|                                                             |                |   |                                       |      | 5-7-1-5  | LANGKA536WJFW | J | Top Angle R                   |      |
|                                                             |                |   |                                       |      | 5-7-1-6  | LHLDZA588WJKZ | J | Lamp Clip, x6                 |      |
|                                                             |                |   |                                       |      | 5-7-1-7  | PGUMMA009WJKA | J | Lamp Rubber, x18              |      |
|                                                             |                |   |                                       |      | 5-7-1-8  | PMiR-A077WJZZ | J | Mirror Sheet                  |      |
| 1                                                           | CCABAA928WJ01  | S | Front Cabinet Ass'y                   |      | 5-7-1-9  | PSPAZA713WJZZ | J | Tape, x2                      | AB   |
| 1-1                                                         | Not Available  | — | Front Cabinet                         |      | 5-7-1-10 | TCAUZA031WJZZ | J | Caution Label                 | AB   |
| 1-2                                                         | GCOVAB240WJSA  | S | R/C, LED Decoration Cover             |      | 5-7-1-11 | XBPS730P06WS0 | J | Screw, x16                    | AA   |
| 1-3                                                         | HBDGBA015WJSA  | S | Badge, "SHARP"                        | AH   |          |               |   |                               |      |
| 1-4                                                         | PSPAHA607WJZZ  | S | Mask Spacer, x2                       |      | 5-7-2    | CHLDZA627WJ01 | J | Panel Holder Ass'y            |      |
| 1-5                                                         | PSPAHA608WJZZ  | S | Mask Spacer, x2                       |      | 5-7-2-1  | Not Available | — | Panel Holder                  |      |
| 1-6                                                         | TLABZB033WJZZ  | S | POP Label                             |      | 5-7-2-2  | PSPAZA669WJZZ | J | Spacer, x2                    | AE   |
|                                                             |                |   |                                       |      | 5-7-2-3  | PSPAZA670WJZZ | J | Spacer, x2                    | AD   |
| 2                                                           | CCABBA574WJ01  | S | Rear Cabinet Ass'y                    |      | 5-7-2-4  | PSPAZA674WJZZ | J | Spacer, x4                    | AB   |
| 2-1                                                         | Not Available  | — | Rear Cabinet                          |      | 5-7-2-5  | PSPAZA675WJZZ | J | Spacer, x6                    | AB   |
| 2-2                                                         | GCOVAB225WJKA  | S | Terminal Cover                        |      | 5-7-2-6  | PSPAZA676WJZZ | J | Spacer, x2                    | AB   |
| 2-3                                                         | LHLDWA055WJKZ  | S | Wire Holder for AC Cord               | AC   |          |               |   |                               |      |
| 2-4                                                         | PSPAHA413WJZZ  | S | Spacer, x2                            | AB   | 5-7-3    | Not Available | — | Lamp Ass'y                    |      |
| 3                                                           | CCOVAB224WJ01  | S | Top Cover ass'y                       |      | 5-7-3-1  | KLMP-A074WJZZ | J | Lamp, x9                      |      |
| 3-1                                                         | Not Available  | — | Top Cover                             |      | 5-7-3-2  | QCNW-D684WJQZ | J | Connector, x8                 |      |
| 3-2                                                         | JBTN-A459WJKA  | S | Power Button                          |      | 5-7-3-3  | QCNW-D687WJQZ | J | Connector                     |      |
| 3-3                                                         | JBTN-A460WJKA  | S | Control Button                        |      |          |               |   |                               |      |
| 3-4                                                         | MSPRCA049WJFW  | S | Power Button Spring                   | AC   | 5-7-4    | LHLDZA589WJKZ | J | Lamp Holder, x2               |      |
| 4                                                           | CDAi-A166WEV2  | S | Stand Ass'y                           |      | 5-7-5    | PCOVUA059WJZZ | J | Diffusion Panel               | BD   |
| 4-1                                                         | CANGTA218WJSA  | S | Stand Bracket Ass'y                   |      | 5-7-6    | PSHEPA354WJZZ | J | Diffusion Sheet, x2           |      |
| 4-1-1                                                       | Not Available  | — | Stand Bracket                         |      | 5-7-7    | XBPS730P06WS0 | J | Screw, x6 (for Lamp Holder)   | AA   |
| 4-1-2                                                       | GDAi-A211WJSA  | S | Stand Support                         |      | 5-7-8    | XBPSN30P10000 | J | Screw, x2                     | AA   |
| 4-2                                                         | CDAi-A166WJKB  | S | Stand Base Ass'y                      |      |          |               |   |                               |      |
| 4-2-1                                                       | Not Available  | — | Stand Base                            |      | 5-8      | LX-BZA051WJFN | J | Screw, x4                     | AB   |
| 4-2-2                                                       | LANGKA406WJSA  | S | Base Bracket                          |      | 5-9      | LX-BZA101WJFN | J | Screw, x8                     | AB   |
| 4-2-3                                                       | PSPAZA476WJZZ  | S | Leg Cushion-B, x2                     | AC   |          |               |   | (for Panel Angle Ass'y)       |      |
| 4-2-4                                                       | PSPAZA477WJZZ  | S | Leg Cushion-C, x4                     | AD   | 5-10     | LX-BZA114WJFN | J | Screw, x4 (for Panel)         |      |
| 4-2-5                                                       | PSPAZA617WJZZ  | S | Leg Cushion-A, x2                     | AC   | 5-11     | TLABN2229TPZZ | J | Code Label                    |      |
| 4-3                                                         | XCBS950P25000  | S | Screw, x5 (for Stand)                 | AC   | 5-12     | XBPS730P06WS0 | J | Screw, x3                     | AA   |
|                                                             |                |   |                                       |      | 5-13     | XBPSN30P10000 | J | Screw, x4                     | AA   |
|                                                             |                |   |                                       |      | 5-14     | XEPS930P10000 | J | Screw, x12                    |      |
| 5                                                           | Not Available  | — | 32 LCD Panel Unit Ass'y               |      | 6        | DUNTKD186DE02 | J | MAIN Unit                     |      |
| 5-1                                                         | RLCDDTA050WJZZ | J | 32 LCD Panel Unit                     |      | 7        | DUNTKD187WE07 | — | AV Unit (LC-32P50E)           | —    |
|                                                             |                |   |                                       |      | 7        | DUNTKD187WE08 | — | AV Unit (LC-32P50K)           | —    |
| 5-2                                                         | CANGKA501WJ01  | J | Panel Fixing Center Angle Ass'y (Top) |      | 7        | DUNTKD187WE10 | — | AV Unit (LC-32P50F)           | —    |
| 5-2-1                                                       | Not Available  | — | Panel Fixing Center Angle (Top)       |      | 7        | DUNTKD187WE11 | — | AV Unit (LC-32P50I)           | —    |
| 5-2-2                                                       | PSHEPA408WJZZ  | J | Sheet (Middle)                        |      | 7        | DUNTKD187WE12 | — | AV Unit (LC-32P50R)           | —    |
| 5-2-3                                                       | PSHEZA030WJZZ  | J | Insulation Sheet, x2 (Long)           | AA   | 8        | DUNTKD188WE07 | — | KEY Unit (LC-32P50E)          | —    |
| 5-2-4                                                       | PSHEZA031WJZZ  | J | Insulation Sheet, x2 (Short)          | AA   | 8        | DUNTKD188WE08 | — | KEY Unit (LC-32P50K)          | —    |
| 5-2-5                                                       | PSPAKA116WJZZ  | J | Angle Sheet, x3                       |      | 8        | DUNTKD188WE10 | — | KEY Unit (LC-32P50F)          | —    |
| 5-2-6                                                       | PTPEZA006WJZZ  | J | Edge Tape, x2                         |      | 8        | DUNTKD188WE11 | — | KEY Unit (LC-32P50I)          | —    |
| 5-2-7                                                       | QEARZA088WJFW  | J | Earth Spacer, x4                      |      | 8        | DUNTKD188WE12 | — | KEY Unit (LC-32P50R)          | —    |
| 5-2-8                                                       | XBPS730P06WS0  | J | Screw, x4 (for Stand)                 | AA   | 9        | DUNTKD189WE07 | — | R/C, LED Unit (LC-32P50E)     | —    |
|                                                             |                |   |                                       |      | 9        | DUNTKD189WE08 | — | R/C, LED Unit (LC-32P50K)     | —    |
| 5-3                                                         | CANGTA188WJ01  | J | Panel Fixing Angle Ass'y (Bottom)     |      | 9        | DUNTKD189WE10 | — | R/C, LED Unit (LC-32P50F)     | —    |
| 5-3-1                                                       | Not Available  | — | Panel Fixing Angle (Bottom)           | AQ   | 9        | DUNTKD189WE11 | — | R/C, LED Unit (LC-32P50I)     | —    |
| 5-3-2                                                       | PSPAKA110WJZZ  | J | Fixing angle Spacer                   | AC   | 9        | DUNTKD189WE12 | — | R/C, LED Unit (LC-32P50R)     | —    |
| 5-3-3                                                       | PSPAZA671WJZZ  | J | Spacer (Short)                        | AE   | 10       | RUNTKA152WJZZ | — | INVERTER Unit                 | —    |
| 5-3-4                                                       | PSPAZA697WJZZ  | J | Spacer, x2 (Short)                    | AB   | 11       | RDENCA122WJZZ | — | POWER Unit                    | —    |
|                                                             |                |   |                                       |      |          |               |   |                               |      |
| 5-4                                                         | CANGTA189WJ01  | J | Panel fixing Angle Ass'y (L-R)        |      | 12       | GCOVAB243WJKA | S | ID Cover                      |      |
| 5-4-1                                                       | Not Available  | — | Panel Fixing Angle (L-R)              | AN   | 13       | GCOVAB263WJKA | S | Hinge Cover                   |      |
| 5-4-2                                                       | PSPAZA672WJZZ  | J | Spacer (Short)                        |      | 13       | HiNDPB295WJSA | S | Model Label (LC-32P50E/K/F)   |      |
|                                                             |                |   |                                       |      | 13       | HiNDPB296WJSA | S | Model Label (LC-32P50I)       |      |
| 5-5                                                         | CANGTA213WJ01  | J | Panel Fixing Angle Ass'y (Top)        |      | 13       | HiNDPB437WJSA | S | Model Label (LC-32P50R)       |      |
| 5-5-1                                                       | Not Available  | — | Panel Fixing Angle (Top)              |      | 14       | LANGTA202WJFW | S | Center Angle                  |      |
| 5-5-2                                                       | PSPAZA671WJZZ  | J | Spacer (Long)                         | AE   | 15       | LCHSMA201WJKA | S | Chassis Frame                 |      |
| 5-5-3                                                       | PSPAZA687WJZZ  | J | Panel Angle Spacer, x4                |      | 16       | LHLDW1009CEZZ | S | Wire Holder (OMEGA Lock)      | AA   |
| 5-5-4                                                       | PSPAZA697WJZZ  | J | Spacer, x2 (Short)                    | AB   | 17       | LHLDW1046CEZZ | S | Wire Holder (OMEGA Lock)      | AA   |
|                                                             |                |   |                                       |      | 18       | LHLDW1173CEZZ | S | Wire Holder (for Back Shield) | AD   |
| 5-6                                                         | CHLDZA558WJ01  | J | Glass Fixing Angle Ass'y, x2          | AF   | 19       | LHLDWA023WJKZ | S | Wire Holder                   | AC   |
| 5-6-1                                                       | Not Available  | — | Glass Fixing Angle, x2                |      | 20       | PRDARA263WJFW | S | Heat Sink                     |      |
| 5-6-2                                                       | PSPAZA674WJZZ  | J | Spacer, x2                            | AB   | 21       | PSLDMA708WJFW | S | Main Shield (Top)             |      |
|                                                             |                |   |                                       |      | 22       | PSLDMA709WJFW | S | Main shield (Bottom)          |      |
| 5-7                                                         | CLAMPA074UJ01  | J | Back Light Ass'y                      |      | 23       | PSLDMA712WJN1 | S | Inverter Shield               |      |
|                                                             |                |   |                                       |      | 24       | PSLDMA769WJFW | S | Tuner Shield                  |      |
| 5-7-1                                                       | CCHSMA206WJ01  | J | Back Light Chassis Ass'y              |      | 25       | PSPAGA243WJZZ | S | Inverter Cushion, x2          |      |
| 5-7-1-1                                                     | Not Available  | — | Back Light Chassis                    |      | 26       | PSPAZA844WJKZ | S | Cooling Sheet for IC3300      |      |
| 5-7-1-2                                                     | LANGFA172WJFW  | J | Angle                                 | AK   | 27       | PSPAZA845WJKZ | S | Cooling Sheet for IC4101      |      |
| 5-7-1-3                                                     | LANGKA459WJFW  | J | Fixing Angle (Bottom)                 | AV   | 28       | PSPAZA846WJKZ | S | Cooling Sheet for IC4503      |      |

| Ref. No.                                                                | Part No.      | ★ | Description                         | Code |
|-------------------------------------------------------------------------|---------------|---|-------------------------------------|------|
| <b>CABINET AND MECHANICAL PARTS<br/>(LC-32P50E/K/F/I/R) (Continued)</b> |               |   |                                     |      |
| 29                                                                      | PSPA848WJKZ   | S | Cooling Sheet for IC1203            |      |
| 30                                                                      | QCNMA201WJZZ  | S | Connecting Cord, MAIN-AV (B to B)   | AH   |
| 31                                                                      | QCNW-D576WJQZ | S | Connecting Cord, AV-KEY             |      |
| 32                                                                      | QCNW-D577WJQZ | S | Connecting Cord, AV-R/C,LED         |      |
| 33                                                                      | QCNW-D578WJQZ | S | Connecting Cord, AV-SP (SP)         |      |
| 34                                                                      | QCNW-D579WJQZ | S | Connecting Cord, AV-POWER           |      |
| 35                                                                      | QCNW-D580WJQZ | S | Connecting Cord, MAIN-POWER (PB)    |      |
| 36                                                                      | QCNW-D581WJQZ | S | Connecting Cord, MAIN-POWER (DP)    |      |
| 37                                                                      | QCNW-D582WJQZ | S | Connecting Cord, INV_GND-GND        |      |
| 38                                                                      | QCNW-D707WJPZ | S | Connecting Cord                     |      |
| 39                                                                      | QCNW-D708WJPZ | S | Connecting Cord                     |      |
| 40                                                                      | QPBMD143WJPZ  | S | Connecting Cord, x2 FPC(80pin)      | AM   |
| 41                                                                      | RSP-ZA120WJZZ | S | Speaker Box (L)                     |      |
| 42                                                                      | RSP-ZA121WJZZ | S | Speaker Box (R)                     |      |
| 43                                                                      | XBBS740P06000 | S | Screw, x7 (for Center Angle)        | AA   |
| 44                                                                      | XBBS930P06000 | S | Screw, x5 (for HDMI/Rear Cabinet)   | AA   |
| 45                                                                      | XBBS940P10000 | S | Screw, x2 (for Hinge Cover)         | AB   |
| 46                                                                      | XBBSN50P12JS0 | S | Screw, x4 (for Stand)               | AF   |
| 47                                                                      | XBPS730P04WS0 | S | Screw, x2 (for Frame)               |      |
| 48                                                                      | XBPS730P06WS0 | S | Screw, x4 (for Stand)               | AA   |
| 49                                                                      | XBPS730P08WS0 | S | Screw, x27 (for PWB)                |      |
| 50                                                                      | XEBS930P08000 | S | Screw, x12 (for Terminal/Top Cover) | AA   |
| 51                                                                      | XEBS940P16000 | S | Screw, x15 (for Rear Cabinet)       | AB   |
| 52                                                                      | XEBSN40P10000 | S | Screw, x3 (for LCD Unit)            | AB   |


# CABINET AND MECHANICAL PARTS (LC-32P50E)



| Ref. No.                                                    | Part No.       | ★ | Description                        | Code | Ref. No. | Part No.      | ★ | Description                              | Code |
|-------------------------------------------------------------|----------------|---|------------------------------------|------|----------|---------------|---|------------------------------------------|------|
| <b>CABINET AND MECHANICAL PARTS<br/>(LC-37P50E/K/F/I/R)</b> |                |   |                                    |      | 5-7-1-6  | LANGKA542WJFW | J | Bracket (Bottom-L)                       |      |
|                                                             |                |   |                                    |      | 5-7-1-7  | LCHSMA220WJZZ | J | Back Light Chassis                       |      |
|                                                             |                |   |                                    |      | 5-7-1-8  | LHLDZA532WJKZ | J | Clip, x6                                 | AD   |
|                                                             |                |   |                                    |      | 5-7-1-9  | LHLDZA576WJKZ | J | Lamp Clip, x10                           | AB   |
|                                                             |                |   |                                    |      | 5-7-1-10 | PGUMMA008WJKA | J | Lamp Rubber, x20                         |      |
|                                                             |                |   |                                    |      | 5-7-1-11 | PMiR-A078WJZZ | J | Mirror Sheet                             |      |
|                                                             |                |   |                                    |      | 5-7-1-12 | PSPAZA713WJZZ | J | Tape, x2                                 | AB   |
|                                                             |                |   |                                    |      | 5-7-1-13 | TCAUZA031WJZZ | J | Caution Label                            | AB   |
|                                                             |                |   |                                    |      | 5-7-1-14 | XBPS730P06WS0 | J | Screw, x17(M3*6)                         | AA   |
|                                                             |                |   |                                    |      | 5-7-2    | CHLDZA633WJ01 | J | Panel Holder, Ass'y                      | BC   |
|                                                             |                |   |                                    |      | 5-7-2-1  | Not Available | — | Panel Hoder                              | AW   |
|                                                             |                |   |                                    |      | 5-7-2-2  | PSPAZA679WJZZ |   | Spacer, x4 (50*3.5*2)                    | AB   |
|                                                             |                |   |                                    |      | 5-7-2-3  | PSPAZA681WJZZ |   | Spacer, x3 (20*3.5*2)                    | AB   |
|                                                             |                |   |                                    |      | 5-7-2-4  | PSPAZA683WJZZ |   | Spacer, x2 (829*4*1.5)                   | AE   |
|                                                             |                |   |                                    |      | 5-7-2-5  | PSPAZA684WJZZ |   | Spacer, x2 (448*4*1)                     | AD   |
|                                                             |                |   |                                    |      | 5-7-2-6  | PSPAZA731WJZZ |   | Spacer, x2                               | AA   |
|                                                             |                |   |                                    |      | 5-7-3    | Not Available | — | Lamp Ass'y                               |      |
|                                                             |                |   |                                    |      | 5-7-3-1  | KLMP-A075WJZZ | J | Lamp, x10                                |      |
|                                                             |                |   |                                    |      | 5-7-3-2  | QCNW-D685WJQZ | J | Connector, x9                            |      |
|                                                             |                |   |                                    |      | 5-7-3-3  | QCNW-D688WJQZ | J | Connector                                |      |
|                                                             |                |   |                                    |      | 5-7-4    | LHLDZA623WJKZ | J | Lamp Holder, x2                          |      |
|                                                             |                |   |                                    |      | 5-7-5    | PCOVUA060WJZZ | J | Diffusion Panel                          | BF   |
|                                                             |                |   |                                    |      | 5-7-6    | PSHEPA355WJZZ | J | Diffusion Sheet, x2                      |      |
|                                                             |                |   |                                    |      | 5-7-7    | XBPS730P08WS0 | J | Screw, x6 (Lamp Holder)                  |      |
|                                                             |                |   |                                    |      | 5-7-8    | XBPSN30P10000 | J | Screw, x2                                | AA   |
|                                                             |                |   |                                    |      | 5-8      | LX-BZA051WJFN | J | Screw, x4 (M4X1)                         | AB   |
|                                                             |                |   |                                    |      | 5-9      | LX-BZA101WJFN | J | Screw, x8 (M3X3.5)                       | AB   |
|                                                             |                |   |                                    |      | 5-10     | LX-BZA114WJFN | J | Screw, x4 (PWB)                          |      |
|                                                             |                |   |                                    |      | 5-11     | TLABN2229TPZZ | J | Code Label                               |      |
|                                                             |                |   |                                    |      | 5-12     | XBPS730P06WS0 | J | Screw, x5 (Top Angle)                    | AA   |
|                                                             |                |   |                                    |      | 5-13     | XBPSN30P10000 | J | Screw, x11<br>(M3X10 Back Light Chassis) | AA   |
|                                                             |                |   |                                    |      | 5-14     | XEPS930P10000 | J | Screw, x4<br>(M3X10 Panel Holder)        |      |
|                                                             |                |   |                                    |      | 6        | DUNTKD186DE03 | J | MAIN Unit                                |      |
|                                                             |                |   |                                    |      | 7        | DUNTKD187WE14 | — | AV Unit (LC-37P50E)                      | —    |
|                                                             |                |   |                                    |      | 7        | DUNTKD187WE16 | — | AV Unit (LC-37P50K)                      | —    |
|                                                             |                |   |                                    |      | 7        | DUNTKD187WE17 | — | AV Unit (LC-37P50F)                      | —    |
|                                                             |                |   |                                    |      | 7        | DUNTKD187WE18 | — | AV Unit (LC-37P50I)                      | —    |
|                                                             |                |   |                                    |      | 7        | DUNTKD187WE19 | — | AV Unit (LC-37P50R)                      | —    |
|                                                             |                |   |                                    |      | 8        | DUNTKD188WE14 | — | KEY Unit (LC-37P50E)                     | —    |
|                                                             |                |   |                                    |      | 8        | DUNTKD188WE16 | — | KEY Unit (LC-37P50K)                     | —    |
|                                                             |                |   |                                    |      | 8        | DUNTKD188WE17 | — | KEY Unit (LC-37P50F)                     | —    |
|                                                             |                |   |                                    |      | 8        | DUNTKD188WE18 | — | KEY Unit (LC-37P50I)                     | —    |
|                                                             |                |   |                                    |      | 8        | DUNTKD188WE19 | — | KEY Unit (LC-37P50R)                     | —    |
|                                                             |                |   |                                    |      | 9        | DUNTKD189WE14 | — | R/C, LED Unit (LC-37P50E)                | —    |
|                                                             |                |   |                                    |      | 9        | DUNTKD189WE16 | — | R/C, LED Unit (LC-37P50K)                | —    |
|                                                             |                |   |                                    |      | 9        | DUNTKD189WE17 | — | R/C, LED Unit (LC-37P50F)                | —    |
|                                                             |                |   |                                    |      | 9        | DUNTKD189WE18 | — | R/C, LED Unit (LC-37P50I)                | —    |
|                                                             |                |   |                                    |      | 9        | DUNTKD189WE19 | — | R/C, LED Unit (LC-37P50R)                | —    |
|                                                             |                |   |                                    |      | 10       | RUNTKA154WJZZ | — | INVERTER Unit                            | —    |
|                                                             |                |   |                                    |      | 11       | RDENCA133WJZZ | — | POWER Unit                               | —    |
|                                                             |                |   |                                    |      | 12       | GCOVAB243WJKA | S | ID Cover                                 |      |
|                                                             |                |   |                                    |      | 13       | GCOVAB263WJKA | S | Hinge Cover                              |      |
|                                                             |                |   |                                    |      | 14       | HiNDPB301WJSA | S | Model Label<br>(LC-37P50E/K/F)           |      |
|                                                             |                |   |                                    |      | 14       | HiNDPB302WJSA | S | Model Label (LC-37P50I)                  |      |
|                                                             |                |   |                                    |      | 14       | HiNDPB438WJSA | S | Model Label (LC-37P50R)                  |      |
|                                                             |                |   |                                    |      | 15       | LANGTA201WJFW | S | Center Angle                             |      |
|                                                             |                |   |                                    |      | 16       | LCHSMA201WJKA | S | Chassis Frame                            |      |
|                                                             |                |   |                                    |      | 17       | LHLDW1009CEZZ | S | OMEGA Lock                               | AA   |
|                                                             |                |   |                                    |      | 18       | LHLDW1046CEZZ | S | OMEGA (Screw)                            | AA   |
|                                                             |                |   |                                    |      | 19       | LHLDW1173CEZZ | S | Wire Holder (Back Shield)                | AD   |
|                                                             |                |   |                                    |      | 20       | LHLDWA023WJKZ | S | -                                        | AC   |
|                                                             |                |   |                                    |      | 21       | PRDARA263WJFW | S | Heat Sink C                              |      |
|                                                             |                |   |                                    |      | 22       | PSLDMA708WJFW | S | Main Shield (Top)                        |      |
|                                                             |                |   |                                    |      | 23       | PSLDMA709WJFW | S | Main Shield (Bottom)                     |      |
|                                                             |                |   |                                    |      | 24       | PSLDMA712WJN1 | S | Inverter Shield                          |      |
|                                                             |                |   |                                    |      | 25       | PSLDMA769WJFW | S | Tuner Shield                             |      |
|                                                             |                |   |                                    |      | 26       | PSPAGA243WJZZ | S | Inverter Cushion, x2                     |      |
|                                                             |                |   |                                    |      | 27       | PSPAZA844WJKZ | S | Cooling Sheet For IC3300                 |      |
| 1                                                           | CCABAA937WJ01  | S | Front Cabinet Ass'y                |      |          |               |   |                                          |      |
| 1-1                                                         | Not Available  | — | Front Cabinet                      | —    |          |               |   |                                          |      |
| 1-2                                                         | GCOVAB240WJSA  | S | R/C, LED Decoration Cover          |      |          |               |   |                                          |      |
| 1-3                                                         | HBDGB3142CESB  | S | Badge, "SHARP"                     |      |          |               |   |                                          |      |
| 1-4                                                         | PSPAHA412WJZZ  | S | Mask Spacer, x2                    | AD   |          |               |   |                                          |      |
| 1-5                                                         | PSPAHA416WJZZ  | S | Mask Spacer, x2                    | AC   |          |               |   |                                          |      |
| 2                                                           | CCABBA578WJ01  | S | Rear Cabinet Ass'y                 |      |          |               |   |                                          |      |
| 2-1                                                         | Not Available  | — | Rear Cabinet                       |      |          |               |   |                                          |      |
| 2-2                                                         | GCOVAB233WJKA  | S | Terminal Cover                     |      |          |               |   |                                          |      |
| 2-3                                                         | LHLDWA055WJKZ  | S | Wire Holder for AC Cord            | AC   |          |               |   |                                          |      |
| 2-4                                                         | PSPAHA413WJZZ  | S | HIMERON                            | AB   |          |               |   |                                          |      |
| 3                                                           | CCOVAB224WJ01  | S | Top Cover Ass'y                    |      |          |               |   |                                          |      |
| 3-1                                                         | Not Available  | — | Top Cover                          |      |          |               |   |                                          |      |
| 3-2                                                         | JBTN-A459WJKA  | S | Power Button                       |      |          |               |   |                                          |      |
| 3-3                                                         | JBTN-A460WJKA  | S | Operation Button                   |      |          |               |   |                                          |      |
| 3-4                                                         | MSPRCA049WJFW  | S | Spring                             | AC   |          |               |   |                                          |      |
| 4                                                           | CDAi-A195WEV2  | S | Stand Ass'y                        |      |          |               |   |                                          |      |
| 4-1                                                         | CANGTA181WJ03  | S | Stand Bracket Ass'y                |      |          |               |   |                                          |      |
| 4-1-1                                                       | Not Available  | — | Stand Bracket                      |      |          |               |   |                                          |      |
| 4-1-2                                                       | GDai-A233WJSA  | S | Stand Support                      |      |          |               |   |                                          |      |
| 4-2                                                         | CDAi-A195WJKB  | S | Stand Base Ass'y                   |      |          |               |   |                                          |      |
| 4-2-1                                                       | Not Available  | — | Stand Base                         |      |          |               |   |                                          |      |
| 4-2-2                                                       | LANGKA443WJSA  | S | Base Bracket                       |      |          |               |   |                                          |      |
| 4-2-3                                                       | PSPAZA476WJZZ  | S | Leg Cushion B, x2                  | AC   |          |               |   |                                          |      |
| 4-2-4                                                       | PSPAZA477WJZZ  | S | Leg Cushion C, x4                  | AD   |          |               |   |                                          |      |
| 4-2-5                                                       | PSPAZA617WJZZ  | S | Leg-Cushion A, x2                  | AC   |          |               |   |                                          |      |
| 4-3                                                         | XCBS950P25000  | S | Screw, x5 (Stand)                  | AC   |          |               |   |                                          |      |
| 5                                                           | Not Available  | — | 37 LCD Panel Unit Ass'y            |      |          |               |   |                                          |      |
| 5-1                                                         | RLCDDTA051WJZZ | J | 37 LCD Panel Unit                  |      |          |               |   |                                          |      |
| 5-2                                                         | CANGKA540WJ01  | J | Top Angke C Ass'y                  |      |          |               |   |                                          |      |
| 5-2-1                                                       | Not Available  | — | Top Angle C                        |      |          |               |   |                                          |      |
| 5-2-2                                                       | PSHEZA035WJZZ  | J | Insulation Sheet (L), X2           |      |          |               |   |                                          |      |
| 5-2-3                                                       | PSHEZA036WJZZ  | J | Insulation Sheet (R), X4           |      |          |               |   |                                          |      |
| 5-2-4                                                       | PTPEZA007WJZZ  | J | Edge Tape, x2                      |      |          |               |   |                                          |      |
| 5-2-5                                                       | QEARZA088WJFW  | J | Earth Spring, x4                   |      |          |               |   |                                          |      |
| 5-2-6                                                       | XBPS730P06WS0  | J | Screw, x4 (CUP)                    | AA   |          |               |   |                                          |      |
| 5-3                                                         | CANGTA190WJ01  | J | Panel Fixing Angle Ass'y (Top)     |      |          |               |   |                                          |      |
| 5-3-1                                                       | Not Available  | — | Panel Fixing Angle (Top)           | AM   |          |               |   |                                          |      |
| 5-3-2                                                       | PSPAZA682WJZZ  | J | Spacer                             | AB   |          |               |   |                                          |      |
| 5-3-3                                                       | PSPAZA685WJZZ  | J | Spacer (829X4X1)                   | AE   |          |               |   |                                          |      |
| 5-3-4                                                       | PSPAZA697WJZZ  | J | Spacer, x2 (13.5X4X1)              | AB   |          |               |   |                                          |      |
| 5-3-5                                                       | PSPAZA755WJZZ  | J | Spacer, x3 (110*5)                 | AD   |          |               |   |                                          |      |
| 5-4                                                         | CANGTA191WJ01  | J | Panel Fixing Angle Ass'y (Bottom)  |      |          |               |   |                                          |      |
| 5-4-1                                                       | Not Available  | — | Panel Fixing Angle (Bottom)        | AM   |          |               |   |                                          |      |
| 5-4-2                                                       | PSPAKA110WJZZ  | J | Spacer                             | AC   |          |               |   |                                          |      |
| 5-4-3                                                       | PSPAZA685WJZZ  | J | Spacer (829X4X1)                   | AE   |          |               |   |                                          |      |
| 5-4-4                                                       | PSPAZA697WJZZ  | J | Spacer, x2 (13.5X4X1)              | AB   |          |               |   |                                          |      |
| 5-5                                                         | CANGTA192WJ01  | J | Panel Fixing Angle Ass'y, x2 (L-R) |      |          |               |   |                                          |      |
| 5-5-1                                                       | Not Available  | — | Panel Fixing Angle, x2 (L-R)       | AK   |          |               |   |                                          |      |
| 5-5-2                                                       | PSPAZA686WJZZ  | J | Spacer, x4 (448X4X2)               | AD   |          |               |   |                                          |      |
| 5-6                                                         | CHLDZA558WJ01  | J | Glass Fixing Angle Ass'y, x2       | AF   |          |               |   |                                          |      |
| 5-6-1                                                       | Not Available  | — | Glass Fixing Angle, x2             |      |          |               |   |                                          |      |
| 5-6-2                                                       | PSPAZA674WJZZ  | J | Spacer, x2 (1.5X16)                | AB   |          |               |   |                                          |      |
| 5-7                                                         | CLAMPA075VJ01  | J | Back Light Ass'y                   |      |          |               |   |                                          |      |
| 5-7-1                                                       | CLAMPA075UJ01  | J | Back Light Chassis Ass'y           |      |          |               |   |                                          |      |
| 5-7-1-1                                                     | Not Available  | — | Back Light Chassis                 |      |          |               |   |                                          |      |
| 5-7-1-2                                                     | LANGFA172WJFW  | J | Angke (Top)                        | AK   |          |               |   |                                          |      |
| 5-7-1-3                                                     | LANGKA538WJFW  | J | Bracket (Top-R)                    |      |          |               |   |                                          |      |
| 5-7-1-4                                                     | LANGKA539WJFW  | J | Bracket (Top-L)                    |      |          |               |   |                                          |      |
| 5-7-1-5                                                     | LANGKA541WJFW  | J | Bracket (Bottom-R)                 |      |          |               |   |                                          |      |

| Ref. No.                                                                | Part No.      | ★ | Description                         | Code |
|-------------------------------------------------------------------------|---------------|---|-------------------------------------|------|
| <b>CABINET AND MECHANICAL PARTS<br/>(LC-37P50E/K/F/I/R) (Continued)</b> |               |   |                                     |      |
| 28                                                                      | PSPA845WJKZ   | S | Cooling Sheet For IC4101            |      |
| 29                                                                      | PSPA846WJKZ   | S | Cooling Sheet For IC4503            |      |
| 30                                                                      | PSPA848WJKZ   | S | Cooling Sheet For IC1203            |      |
| 31                                                                      | QCNCMA201WJZZ | S | Connecting cord<br>(MAIN-AV BTOB)   | AH   |
| 32                                                                      | QCNW-D846WJQZ | S | Connecting cord (AV-KEY)            |      |
| 33                                                                      | QCNW-D847WJQZ | S | Connecting cord (AV-R/C)            |      |
| 34                                                                      | QCNW-D848WJQZ | S | Connecting cord (SP(AV-SP))         |      |
| 35                                                                      | QCNW-D849WJQZ | S | Connecting cord (AV-Power)          |      |
| 36                                                                      | QCNW-D850WJQZ | S | Connecting cord<br>(MAIN-Power(PB)) |      |
| 37                                                                      | QCNW-D851WJQZ | S | Connecting cord<br>(MAIN-Power(PC)) |      |
| 38                                                                      | QCNW-D852WJQZ | S | Connecting cord<br>(INV_GND-GND)    |      |
| 39                                                                      | QCNW-D854WJPZ | S | Connecting cord<br>(POW-INV(PD))    |      |
| 40                                                                      | QCNW-D855WJPZ | S | Connecting cord<br>(POW-INV(PF))    |      |
| 41                                                                      | QPWBMD143WJPZ | S | FPC(80pin), x2                      | AM   |
| 42                                                                      | RSP-ZA120WJZZ | S | Speaker Box (L)                     |      |
| 43                                                                      | RSP-ZA121WJZZ | S | Speaker Box (R)                     |      |
| 44                                                                      | XBBS740P06000 | S | Screw, x7 (Center Angle)            | AA   |
| 45                                                                      | XBBS930P06000 | S | Screw, x5<br>(HDMI/Rear Cabinet)    | AA   |
| 46                                                                      | XBBS940P10000 | S | Screw, x2 (Hinge Cover)             | AB   |
| 47                                                                      | XBBSN50P12JS0 | S | Screw, x4 (Stand)                   | AF   |
| 48                                                                      | XBPS730P04WS0 | S | Screw, x2 (EAR-PWB/FRM)             |      |
| 49                                                                      | XBPS730P06WS0 | S | Screw, x4 (Inverter/Power)          | AA   |
| 50                                                                      | XBPS730P08WS0 | S | Screw, x28 (PWB)                    |      |
| 51                                                                      | XEBS930P08000 | S | Screw, x12 (Terminal)               | AA   |
| 52                                                                      | XEBS940P16000 | S | Screw, x15 (Rear Cabinet)           | AB   |
| 53                                                                      | XEBSN40P10000 | S | Screw, x3 (LED Unit)                | AB   |

# CABINET AND MECHANICAL PARTS (LC-37P50E)



| Ref. No. | Part No. | ★ | Description | Code |
|----------|----------|---|-------------|------|
|----------|----------|---|-------------|------|




## SUPPLIED ACCESSORIES

| LC-26P50E/K/F//R |                |   |                                     |    |
|------------------|----------------|---|-------------------------------------|----|
| X1               | LHLDW0110CEZZ  | S | Cable Clamp                         | AE |
| X2               | LHLDWA083WJ00  | S | Cable Band                          |    |
| X3               | QACCKA007WJPZ  | S | AC Code (LC-26P50E/F//R) AK         |    |
| X3               | QACCBAA021WJPZ | S | AC Code (LC-26P50EK)                |    |
| X4               | RRMCGA387WJSA  | S | Infrared Remote Control             |    |
| X5               | SSAKAA009WJZZ  | S | Polyethylene Back                   |    |
| X6               | SSAKAA010WJZZ  | S | Polyethylene Back                   |    |
| X7               | TGAN-1688CEN1  | S | Guarantee Card (LC-26P50E(K))       |    |
| X7               | TGAN-A077WJZZ  | S | Warranty Card (LC-26P50E(R))        |    |
| X8               | TiNS-B845WJZZ  | S | Operation Manual (LC-26P50E/K/F//I) |    |
| X9               | TiNS-B846WJZZ  | S | Operation Manual (LC-26P50E/F)      |    |
| X10              | TiNS-B847WJZZ  | S | Operation Manual (LC-26P50E)        |    |
| X11              | TiNS-B854WJZZ  | S | Operation Manual (LC-26P50R)        |    |
| LC-32P50E/K/F//R |                |   |                                     |    |
| X1               | LHLDW0110CEZZ  | S | Cable Clamp                         | AE |
| X2               | LHLDWA083WJ00  | S | Cable Band                          |    |
| X3               | QACCBAA021WJPZ | S | AC Code (LC-32P50K)                 |    |
| X3               | QACCKA007WJPZ  | S | AC Code (LC-32P50E/F//R) AK         |    |
| X4               | RRMCGA387WJSA  | S | Infrared Remote Control             |    |
| X5               | SSAKAA009WJZZ  | S | Polyethylene Back                   |    |
| X6               | SSAKAA010WJZZ  | S | Polyethylene Back                   |    |
| X7               | TGAN-1688CEN1  | S | Guarantee Card (LC-32P50K)          |    |
| X7               | TGAN-A077WJZZ  | S | Warranty Card (LC-32P50R)           |    |
| X8               | TiNS-B845WJZZ  | S | Operation Manual (LC-32P50E/K/F//I) |    |
| X9               | TiNS-B846WJZZ  | S | Operation Manual (LC-32P50E/F)      |    |
| X10              | TiNS-B847WJZZ  | S | Operation Manual (LC-32P50E)        |    |
| X11              | TiNS-B854WJZZ  | S | Operation Manual (LC-32P50R)        |    |
| LC-37P50E/K/F//R |                |   |                                     |    |
| X1               | LHLDW0110CEZZ  | S | Cable Clamp                         | AE |
| X2               | LHLDWA083WJ00  | S | Cable Band                          |    |
| X3               | QACCBAA021WJPZ | S | AC Cord (LC-37P50K)                 | AK |
| X3               | QACCKA007WJPZ  | S | AC Cord (LC-37P50E/F//R)            |    |
| X4               | RRMCGA387WJSA  | S | Remote Control Unit                 |    |
| X5               | SSAKAA009WJZZ  | S | Polyethylene Back                   |    |
| X6               | SSAKAA010WJZZ  | S | Polyethylene Back                   |    |
| X7               | TGAN-1688CEN1  | S | Guarantee Card (LC-37P50K)          |    |
| X7               | TGAN-A077WJZZ  | S | Warranty Card (LC-37P50R)           |    |
| X8               | TiNS-B845WJZZ  | S | Operation Manual (ENGLISH..)        |    |
| X9               | TiNS-B846WJZZ  | S | Operation Manual (SWEDISH..)        |    |
| X10              | TiNS-B847WJZZ  | S | Operation Manual (POLISH..)         |    |
| X11              | TiNS-B854WJZZ  | S | Operation Manual (LC-37P50E)        |    |
| X12              | TLABN0134BMZZ  | S | Sees No. Label                      |    |
| X13              | TLABNB415WJZZ  | S | No. Label                           |    |

| Ref. No. | Part No. | ★ | Description | Code |
|----------|----------|---|-------------|------|
|----------|----------|---|-------------|------|

## PACKING PARTS (NOT REPLACEMENT ITEM)

| LC-26P50E/K/F//R |               |   |                          |   |
|------------------|---------------|---|--------------------------|---|
| S1               | SPAKCB951WJZZ | - | Packing Case             | — |
| S2               | SPAKFA788WJZZ | - | Accessory Case           | — |
| S3               | SPAKFA822WJZZ | - | Stand Pad                | — |
| S4               | SPAKFA870WJZZ | - | Bottom Pad               | — |
| S5               | SPAKPA396WJZZ | - | Wrapping Paper (Display) | — |
| S6               | SPAKPA391WJZZ | - | Wrapping Paper (Stand)   | — |
| S7               | SPAKXA759WJZZ | - | Pad                      | — |
| S9               | TLABSA053WJZZ | - | Gost Label (LC-26P50R)   | — |
| S11              | TLABZA792WJZZ | - | EICTA Label              | — |
| S12              | TLABKA002WJZZ | - | Bar Code Label           | — |
| LC-32P50E/K/F//R |               |   |                          |   |
| S1               | SPAKCB952WJZZ | - | Packing Case             | — |
| S2               | SPAKFA788WJZZ | - | Accessory Case           | — |
| S3               | SPAKFA821WJZZ | - | Stand Pad                | — |
| S4               | SPAKFA869WJZZ | - | Bottom Pad               | — |
| S5               | SPAKPA382WJZZ | - | Wrapping Paper (Display) | — |
| S6               | SPAKPA377WJZZ | - | Wrapping Paper (Stand)   | — |
| S7               | SPAKXA760WJZZ | - | Pad                      | — |
| S9               | TLABSA053WJZZ | - | Gost Label (LC-32P50R)   | — |
| S10              | TLABSA050WJZZ | - | Gost Label (LC-32P50F)   | — |
| S11              | TLABZA792WJZZ | - | EICTA Label (LC-32P50R)  | — |
| S12              | TLABKA002WJZZ | - | Bar Code Label           | — |
| LC-37P50E/K/F//R |               |   |                          |   |
| S1               | SPAKCB953WJZZ | - | Packing Case             | — |
| S2               | SPAKFA788WJZZ | - | Accessories Case         | — |
| S3               | SPAKFA833WJZZ | - | Stand Pad                | — |
| S4               | SPAKFA871WJZZ | - | Bottom Pad               | — |
| S5               | SPAKPA338WJZZ | - | Wrapping Paper           | — |
| S6               | SPAKPA377WJZZ | - | Wrapping Paper           | — |
| S7               | SPAKXA761WJZZ | - | Pad                      | — |
| S8               | TLABZB033WJZZ | - | POP Label                | — |
| S9               | TLABSA053WJZZ | - | Gost Label (LC-37P50R)   | — |
| S10              | TLABSA050WJZZ | - | Label (LC-37P50F)        | — |
| S11              | TLABZA792WJZZ | - | EICTA Label              | — |
| S12              | TLABKA002WJZZ | - | Case No. Label           | — |

| Cable clamp (X1)                                                                                                                | Cable band (X2)                                                                       |
|---------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|                                              |  |
| AC cord (X3)                                                                                                                    | Remote control unit (X4)                                                              |
| <br>Product shape varies in some countries. |  |

## PACKING OF THE SET

