V. EXPLODED VIEWS

Note: 1. LUBRICATION POINTS

1 Transport Section

When the marked parts are replaced, apply the recommended Lubricants or adhesive for better maintenance of the unit.

Mark	Kind of Lubricant	Availability	Part Number
	Molytone Grease	Available From Factory	MOR265
000	Spindle Oil	Purchase From Local Supplier	
$\Delta \Delta \Delta$	Grease	Available From Factory	VFKS0081

2. 700 series parts with 🔘 are not available as replacement parts. (121); (131) The same of 73 45) **(9)** 409 703; 36) 2 **(87)** 716; *1 As an ESD Countermeasure, the spring should be installed in the proper position. Please refer to Disassembly/Assembly Section for more information.