


5. Exploded View & Part List


5-1 PS63C7700YSXXN Exploded View



■ Part List

Loc. No.	Part No.	Description;Specification	Qty.	SNA	Remark
AC280	BN63-06767A	COVER-PCB;UC8K,HIPS,V0, BLK	1	SNA	
F001	BN63-06524B	COVER-FRONT;63PC7000,PC(Clear)+PC(Charco	1	SNA	
F001A	BN96-12997A	ASSY COVER P-FRONT;PC7000 63,PC(Clear)+P	1	SA	
FB21A	BN96-14504B	ASSY BOARD P-TOUCH FUNCTION&IR;63PC7000,	1	SA	
HC001	BN61-04922A	HOLDER-CORD;LB7000 46,ABS,V0,BLK	1	SA	
M0014	BN94-03326F	ASSY PCB MISC-MAIN;PS63C7780YSXZG	1	SA	△
R001A	BN96-13010A	ASSY COVER P-REAR;PC7000 63,PCM,T0.45,BK	1	SA	
SB04A	BN96-13026A	ASSY STAND P-BASE;PC7000 58,SUS T0.6	1	SA	
SP01A	BN96-12942C	ASSY SPEAKER P;8ohm,4pin,15,L:280 R:900,	1	SA	
SP01A	BN96-13273C	ASSY SPEAKER P;4ohm,4pin,25W,R:960,Enclo	1	SA	
U001A	BN96-13447A	ASSY PDP MODULE P;S63FH-YB05,PL63FF012B,	1	SA	△

5-2 PS63C7705YSXXE Exploded View



■ Part List

Loc. No.	Part No.	Description;Specification	Qty.	SNA	Remark
AC280	BN63-06767A	COVER-PCB;UC8K,HIPS,V0, BLK	1	SNA	
F001	BN63-06524B	COVER-FRONT;63PC7000,PC(Clear)+PC(Charco	1	SNA	
F001A	BN96-12997A	ASSY COVER P-FRONT;PC7000 63,PC(Clear)+P	1	SA	
FB21A	BN96-14504B	ASSY BOARD P-TOUCH FUNCTION&IR;63PC7000,	1	SA	
HC001	BN61-04922A	HOLDER-CORD;LB7000 46,ABS,V0,BLK	1	SA	
M0014	BN94-03326G	ASSY PCB MISC-MAIN;PS63C7705YSXXE	1	SA	△
R001A	BN96-13010A	ASSY COVER P-REAR;PC7000 63,PCM,T0.45,BK	1	SA	
SB04A	BN96-13026A	ASSY STAND P-BASE;PC7000 58,SUS T0.6	1	SA	
SP01A	BN96-12942C	ASSY SPEAKER P;8ohm,4pin,15,L:280 R:900,	1	SA	
SP01A	BN96-13273C	ASSY SPEAKER P;4ohm,4pin,25W,R:960,Enclo	1	SA	
U001A	BN96-13447A	ASSY PDP MODULE P;S63FH-YB05,PL63FF012B,	1	SA	△

5-3 PS63C7700YSXXN Service Item

Loc. No.	Part No.	Description;Specification	Qty.	Remark
SP01A	BN96-12942C	ASSY SPEAKER P;8ohm,4pin,15,L:280 R:900,	1	
F001A	BN96-12997A	ASSY COVER P-FRONT;PC7000 63,PC(Clear)+P	1	
FB21A	BN96-14504B	ASSY BOARD P-TOUCH FUNCTION&IR;63PC7000,	1	
R001A	BN96-13010A	ASSY COVER P-REAR;PC7000 63,PCM,T0.45,BK	1	
SB04A	BN96-13026A	ASSY STAND P-BASE;PC7000 58,SUS T0.6	1	
SG03	BN61-06119A	GUIDE-STAND;58PC6500,PC,G/F 20%,V2,BK000	1	
M2893	BN39-01267E	LEAD CONNECTOR;LB6T,FLAT CONNECTOR ASS'Y	1	
P001A	BN44-00334A	DC VSS-PDP TV;PZ-8A,AC/DC,AC100~240V,50/	1	△
M0014	BN94-03326F	ASSY PCB MISC-MAIN;PS63C7780YSXZG	1	△
ET01	BN40-00175A	TUNER;DNSS24CVH161A,DVB-T/C+S2,164CH,38.	1	
IC125	BN13-00031A	IC ASIC;LUNA,SDP95,400,3.6,-40to+125C,CA	1	
FL06	BN96-12723T	ASSY CABLE P-FPCB LVDS;PDP 63 U/SLIM,FPC	1	
SP01A	BN96-13273C	ASSY SPEAKER P;4ohm,4pin,25W,R:960,Enclo	1	
U001A	BN96-13447A	ASSY PDP MODULE P;S63FH-YB05,PL63FF012B,	1	△
UX03A	BN96-12689A	ASSY PDP P-X MAIN BOARD;S63-FH-YB05,PL63	1	△
UX02A	BN96-12690A	ASSY PDP P-X BUFFER UPPER BOARD;S63-FH-Y	1	
UX01A	BN96-12691A	ASSY PDP P-X BUFFER LOWER BOARD;S63-FH-Y	1	
UY04A	BN96-12692A	ASSY PDP P-Y MAIN BOARD;S63-FH-YB05,PL63	1	△
UY03A	BN96-12693A	ASSY PDP P-Y BUFFER UPPER BOARD;S63-FH-Y	1	
UY02A	BN96-12694A	ASSY PDP P-Y BUFFER LOWER BOARD;S63-FH-Y	1	
UE01A	BN96-12696A	ASSY PDP P-E-BUFFER BOARD;S63-FH-YB05,PL	1	
UF01A	BN96-12697A	ASSY PDP P-F-BUFFER BOARD;S63-FH-YB05,PL	1	
UG02A	BN96-12698A	ASSY PDP P-G-BUFFER BOARD;S63-FH-YB05,PL	1	
UL01A	BN96-14112A	ASSY PDP P-LOGIC MAIN BOARD;S63FH-YB05,P	1	
EC11	BN96-09872S	ASSY POWER CORD;16A/250V, IEC,LP-33R,Y,P	1	△
HC001	BN61-04922A	HOLDER-CORD;LB7000 46,ABS,V0,BLK	1	
T0214	AA61-20285C	HOLDER-BOX;CORAL,PP,BLACK,HB,17.5g	4	
M0114	BN39-01154C	CBF SIGNAL;Chelsea Slim, STEREO Plug to	1	
M0114	BN39-01154F	CBF SIGNAL;UE40B7000WWXXC,24P/20P,30AWG,	1	
M0114	BN39-01154H	CBF SIGNAL;UE40B7000WWXXC,RCA 3PIN,30AWG	1	
REMO2	BN59-01054A	REMOCON;TM1080,SAMSUNG,20PIN SINGLE,49KE	1	
	BN61-05596A	HOLDER-WIRE CABLE;LED TV,LDPE,T0.8,L150,	1	
M9889	BN63-01798B	CLOTH-CLEAN;cloth,180,200,sea blue,ToC	1	
EH02A	BN96-10810A	ASSY HOLDER P;09 LEDTV MODEL,NYRON	1	
RB01	BN63-06485C	COVER-BOTTOM;58PC6500,PC+ABS,V0,BK0008	1	

5-4 PS63C7705YSXXE Service Item

Loc. No.	Part No.	Description;Specification	Qty.	Remark
SP01A	BN96-12942C	ASSY SPEAKER P;8ohm,4pin,15,L:280 R:900,	1	
F001A	BN96-12997A	ASSY COVER P-FRONT;PC7000 63,PC(Clear)+P	1	
FB21A	BN96-14504B	ASSY BOARD P-TOUCH FUNCTION&IR;63PC7000,	1	
R001A	BN96-13010A	ASSY COVER P-REAR;PC7000 63,PCM,T0.45,BK	1	
SB04A	BN96-13026A	ASSY STAND P-BASE;PC7000 58,SUS T0.6	1	
SG03	BN61-06119A	GUIDE-STAND;58PC6500,PC,G/F 20%,V2,BK000	1	
HC001	BN61-04922A	HOLDER-CORD;LB7000 46,ABS,V0,BLK	1	
M2893	BN39-01267E	LEAD CONNECTOR;LB6T,FLAT CONNECTOR ASS'Y	1	
P001A	BN44-00334A	DC VSS-PDP TV;PZ-8A,AC/DC,AC100~240V,50/	1	△
M0014	BN94-03326G	ASSY PCB MISC-MAIN;PS63C7705YSXXE	1	△
ET01	BN40-00175A	TUNER;DNSS24CVH161A,DVB-T/C+S2,164CH,38.	1	
IC125	BN13-00031A	IC ASIC;LUNA,SDP95,400,3.6,-40to+125C,CA	1	
FL06	BN96-12723T	ASSY CABLE P-FPCB LVDS;PDP 63 U/SLIM,FPC	1	
SP01A	BN96-13273C	ASSY SPEAKER P;4ohm,4pin,25W,R:960,Enclo	1	
U001A	BN96-13447A	ASSY PDP MODULE P;S63FH-YB05,PL63FF012B,	1	△
UX03A	BN96-12689A	ASSY PDP P-X MAIN BOARD;S63-FH-YB05,PL63	1	△
UX02A	BN96-12690A	ASSY PDP P-X BUFFER UPPER BOARD;S63-FH-Y	1	
UX01A	BN96-12691A	ASSY PDP P-X BUFFER LOWER BOARD;S63-FH-Y	1	
UY04A	BN96-12692A	ASSY PDP P-Y MAIN BOARD;S63-FH-YB05,PL63	1	△
UY03A	BN96-12693A	ASSY PDP P-Y BUFFER UPPER BOARD;S63-FH-Y	1	
UY02A	BN96-12694A	ASSY PDP P-Y BUFFER LOWER BOARD;S63-FH-Y	1	
UE01A	BN96-12696A	ASSY PDP P-E-BUFFER BOARD;S63-FH-YB05,PL	1	
UF01A	BN96-12697A	ASSY PDP P-F-BUFFER BOARD;S63-FH-YB05,PL	1	
UG02A	BN96-12698A	ASSY PDP P-G-BUFFER BOARD;S63-FH-YB05,PL	1	
UL01A	BN96-14112A	ASSY PDP P-LOGIC MAIN BOARD;S63FH-YB05,P	1	
EC11	BN96-09872S	ASSY POWER CORD;16A/250V, IEC,LP-33R,Y,P	1	△
T0214	AA61-20285C	HOLDER-BOX;CORAL,PP,BLACK,HB,17.5g	4	
M0114	BN39-01154C	CBF SIGNAL;Chelsea Slim, STEREO Plug to	1	
M0114	BN39-01154F	CBF SIGNAL;UE40B7000WWXXC,24P/20P,30AWG,	1	
M0114	BN39-01154H	CBF SIGNAL;UE40B7000WWXXC,RCA 3PIN,30AWG	1	
REMO2	BN59-01054A	REMOCON;TM1080,SAMSUNG,20PIN SINGLE,49KE	1	
	BN61-05596A	HOLDER-WIRE CABLE;LED TV,LDPE,T0.8,L150,	1	
M9889	BN63-01798B	CLOTH-CLEAN;cloth,180,200,sea blue,ToC	1	
EH02A	BN96-10810A	ASSY HOLDER P;09 LEDTV MODEL,NYRON	1	
RB01	BN63-06485C	COVER-BOTTOM;58PC6500,PC+ABS,V0,BK0008	1	

MEMO