
EXPLODED VIEW

Control Panel & Top plate Assembly



EXPLODED VIEW


Cabinet Cover & Door Assembly (B100) B108 (B103) (B104) B106 B102 B101 B105 B126 (B127) (B128) **B**129 **B**130 **B**124 (B131) (B140) (B141) **B**123 (B150) (B122) B120 **B**136 B132 (B121) **B**160

41

13

EXPLODED VIEW

Base & Motor Assembly



EXPLODED VIEW

Back Cover & Drum Assembly

