


8-1-2. FRONT PANEL SECTION



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
51	3-081-146-02	PANEL, ALUMINUM		61	3-081-125-01	BASE, DOOR	
52	3-081-147-01	WINDOW, INDICATION		62	3-081-117-01	BUTTON, CONTROL	
53	3-081-126-02	DOOR, ALUMINUM (AEP)		63	3-081-118-01	INDICATOR (PLAY)	
53	3-081-126-32	DOOR, ALUMINUM (UK)		64	3-081-130-01	SHAFT (L)	
54	4-921-277-11	SCREW (B2.6X8), TAPPING, BIND		65	3-081-156-01	CUSHION, DRIVE	
55	3-081-128-01	PLATE, GROUND DOOR		66	3-080-678-01	PANEL, BASE	
56	3-081-127-01	RETAINER, MAGNET		67	3-081-119-02	SPRING, GROUND	
57	3-081-129-01	SHAFT (R)		68	X-3953-197-1	BUTTON ASSY, POWER	
58	3-736-779-71	MAGNET		69	X-3953-196-1	BUTTON ASSY, PLAY	
59	3-081-131-01	SHAFT (C)		70	3-081-428-01	CUSHION, DOOR	
60	3-047-468-01	DAMPER		71	3-083-631-01	DAMPER, SUUND	