


Nr.	ASWO-Nº
G010	382 18 01
G030	382 18 02
G520	278 22 31
G560	207 61 01
G580	278 22 32
G590	278 22 33
G680	216 27 99
G690	215 86 81



*) Diese Teile müssen gerätespezifisch bestellt werden, da sie teilweise unterschiedlich sind!
 These parts must be ordered by the specific model number, since they are not interchangeable!
 Ces pièces doivent être commandées par rapport au modèle, car elles diffèrent selon les versions!
 Questi pezzi devono essere ordinati secondo il tipo di apparecchio, perché parzialmente differenti!