




BOSCH

Maxx – WFL1860FF/01–V01
Maxx – WFL1860FF/02–V02

LAVAGE
Machine à laver



Instructions d'usage +
Instructions d'installation +
Tableau des programmes
52 3776
(FR)


VDE – Couverture
21 5174



BOSCH

Maxx – WFL1860FF/01–V01
Maxx – WFL1860FF/02–V02

LAVAGE
Machine à laver




AET5830000083351000

**BOSCH**

Maxx – WFL1860FF/01–V01
 Maxx – WFL1860FF/02–V02

LAVAGE
 Machine à laver




1) 26 5964

AET5830000083351000

**BOSCH**

Maxx – WFL1860FF/01–V01
Maxx – WFL1860FF/02–V02

LAVAGE
Machine à laver



	ASKOLL	COPRECI
1	17 2340	17 2337
2	15 1408	15 4358
3		172338
4	15 1409	
5		17 2339